

TDS PRODUCT IMAGE SHEET > **DEANS – DOOR LEAVES & SHAFTS**

Image	TDS Part Number & Description	OE Part Numbers
	<p><b>PVT010A</b> ENT DOOR HINGE BLOCK LONG</p>	<p><b>E25408</b> <i>Deans</i></p>
	<p><b>PVT011A</b> ENT DOOR HINGE BLOCK SHORT</p>	<p><b>E25407</b> <i>Deans</i></p>
	<p><b>PVT015A</b> LOWER HINGE PIVOT BRACKET</p>	<p><b>D31431</b> <i>Deans</i></p>
	<p><b>PVT016A</b> UPPER HINGE PIVOT BRACKET</p>	<p><b>D31388</b> <i>Deans</i></p>
	<p><b>PVT029</b> LOWER PIVOT ARM ASSY (DEANS PS)</p>	<p><b>088099</b> <i>Deans</i></p>
	<p><b>ASY003B</b> UNIVERSAL GUIDE SPINDLE LONG</p>	<p><b>H102250</b> <i>Deans</i> <b>H105408</b> <i>Deans</i></p>

	<p><b>ASY004B</b> UNIVERSAL GUIDE SPINDLE SHORT</p>	<p><b>0123268</b> <i>Deans</i> <b>H102249</b> <b>033889B-10A</b></p>
	<p><b>ASY006B</b> INLINE BOTTOM BEARING – 25mm ROLLER</p>	<p><b>75-22155</b> <i>Deans</i></p>
	<p><b>ASY008A</b> INLINE BOTTOM BEARING – 32mm ROLLER</p>	<p><b>D21059</b> <i>Deans</i></p>
	<p><b>ASY010A</b> SOLO INLINE UNIVERSAL BOTTOM BEARING – 32mm ROLLER</p>	<p><b>032024</b> <i>Deans</i> <b>032025</b> <i>Deans</i></p>
	<p><b>ASY013A</b> TRI BOTTOM BEARING – 25mm ROLLER</p>	<p><b>C25245</b> <i>Deans</i></p>
	<p><b>ASY014A</b> TRI BOTTOM BEARING – 32mm ROLLER</p>	<p><b>C23262</b> <i>Deans</i> <b>C23632</b> <i>Deans</i> <b>C44067</b> <i>Deans</i></p>
	<p><b>ASY019A</b> M10 SPH BEARING PLATE ASSY</p>	<p><b>045470</b> <i>Deans</i> <b>D34018</b> <i>Deans</i> <b>031821</b> <i>Deans</i></p>


	<p><b>ASY023T</b> SPINDLE ASSY LONG 97mm (026426)</p>	<p><b>026426 Assy Deans</b></p>
	<p><b>ASY024T</b> SPINDLE ASSY SHORT 71mm (026425)</p>	<p><b>026425 Assy Deans</b></p>
	<p><b>ASY025</b> PIVOT BRACKET ASSY KIT DEANS</p>	<p><b>H105023 Deans</b></p>
	<p><b>ASY026</b> RH BOTTOM BEARING ASSEMBLY DEANS</p>	<p><b>H102724 Deans</b></p>
	<p><b>ASY027</b> PIVOT BRACKET ASSY KIT DEANS</p>	<p><b>H105021 Deans</b></p>
	<p><b>ASY040</b> BOTTOM BEARING BRACKET KKT Ø12 SPH BEARING</p>	<p><b>H102923 Deans</b></p>
	<p><b>ASY043</b> LH GUIDE BRKT+SPINDLE ASSY (LONG) - (BRK054+ASY003)</p>	<p><b>0104967 Deans</b></p>

	<p><b>ASY044=</b> RH GUIDE BRKT+SPINDLE ASSY (LONG) (BRK055+ASY003)</p>	<p><b>0104968</b> Deans</p>
	<p><b>ASY058</b> DEANS RH GUIDE ASSY (RLR005)</p>	<p><b>D17984</b> Deans</p>
	<p><b>SPL023</b> DEANS 16DIA DR/GUIDE SPINDLE LONG</p>	<p><b>026426</b> Deans</p>
	<p><b>SPL024</b> DEANS 16DIA DR/GUIDE SPINDLE SHORT</p>	<p><b>026425</b> Deans</p>
	<p><b>SPA037</b> REAR PIVOT BEARING SPACER (DEANS 106981)</p>	<p><b>106981</b> Deans</p>
	<p><b>CIR009A</b> EXTERNAL CIRCLIP 1400-3/8</p>	<p><b>070002</b> Deans <b>75-19627</b> Deans USED ON DEANS 16DIA DR/GUIDE SPINDLES</p>
	<p><b>SPG008</b> DEANS SMALL 600mm SPRING</p>	<p><b>0104492</b> Deans</p>
	<p><b>SPG017</b> DR FLAP RETURN SPRING NO.1 - DEANS</p>	<p><b>D49821</b> Deans</p>



	<p><b>SPG018</b> DR FLAP RETURN SPRING NO.2 - DEANS</p>	<p><b>D49882</b> <i>Deans</i></p>
	<p><b>STB015</b> DRIVE SHAFT</p>	<p><b>H102186</b> <i>Deans</i></p>
	<p><b>STB016</b> DRIVE SHAFT CLAMP PLATE</p>	<p><b>H102189</b> <i>Deans</i></p>
	<p><b>ASY033</b> RH SIDE No.1 DOOR BOTTOM BEARING ASSY</p>	<p><b>0101567</b> <i>Deans</i></p>
	<p><b>ASY034</b> LH SIDE No2 DOOR BOTTOM BEARING ASSY</p>	<p><b>0101568</b> <i>Deans</i></p>
	<p><b>BRK029</b> GUIDE BRACKET KIT DEANS</p>	<p><b>H104566</b> <i>Deans</i></p>
	<p><b>BRK049</b> LH SUPPORT BRACKET</p>	<p><b>027946</b> <i>Deans</i></p>

	<p><b>BRK050</b> RH SUPPORT BRACKET</p>	<p><b>027947</b> <i>Deans</i></p>
	<p><b>BRK054</b> LH NO.1 DOOR GUIDE BRACKET (KKT DOOR)</p>	<p><b>H102945</b> <i>Deans</i></p>
	<p><b>BRK055</b> RH NO.2 DOOR GUIDE BRACKET (KKT DOOR)</p>	<p><b>H102946</b> <i>Deans</i></p>
	<p><b>BRK067</b> CORNER INSERT DEANS KEIKERT BONDED GLAZING DOORS</p>	<p><b>C49800</b> <i>Deans</i></p>
	<p><b>BRK068</b> RH No.1 Door. BOTTOM LEADING EDGE BRACKET DEANS KEIKERT BONDED GLAZING DOORS</p>	<p><b>H107216</b> <i>Deans</i></p>
	<p><b>BRK069</b> LH No.2 Door. BOTTOM LEADING EDGE BRACKET DEANS KEIKERT BONDED GLAZING DOORS</p>	<p><b>H107217</b> <i>Deans</i></p>

	<p><b>BRK071</b> No1 LH DOORGUIDE BRACKET</p>	<p><b>027724</b> <i>Deans</i></p>
	<p><b>BRK072</b> No2 RH DOORGUIDE BRACKET</p>	<p><b>027725</b> <i>Deans</i></p>
	<p><b>BRG010B</b> M12x1.75 RH MALE SPH RODEND</p>	<p><b>049651</b> <i>Deans</i></p>
	<p><b>BRG012B-ASSY</b> 1/2 UNF RH MALE SPH RODEND ASSY</p>	<p><b>E11311</b> <i>Deans</i></p>
	<p><b>BRG013B-ASSY</b> 7/16 UNF RH MALE SPH RODEND ASSY</p>	<p><b>E13306</b> <i>Deans</i></p>
 <p><b>BRG019B</b></p>	<p><b>BRG019B</b> Ø 10mm SPH BEARING RACE O/D=26x10.5 (ALT SEE BRG019C)</p>	<p><b>041339</b> <i>Deans</i></p>
	<p><b>BRG037</b> Ø 14 SPH BEARING KGLM-14 OD=28x13.5</p>	<p><b>0100605</b> <i>Deans</i></p>

	<p><b>BRG046</b> Ø 12 SPH BEARING EGLM-12 OD=22x7</p>	<p><b>0100606</b> <i>Deans</i></p>
	<p><b>BRG056</b> TRACK ROD END - B10B</p>	<p><b>080073</b> <i>Deans</i></p>
	<p><b>BRG058</b> Ø 6 PLUG SLIDER LOWER SHAFT GUIDE RADIAL BEARING OD=19x6</p>	<p><b>0102265</b> <i>Deans</i></p>
	<p><b>BRG068B</b> Ø 10 x 6 x 12od NY-SLEEVE</p>	<p><b>0101454</b> <i>Deans</i> <i>Plug slider lower arm</i></p>
	<p><b>BRG074</b> 7/16"UNF LH MALE SPH RODEND</p>	<p><b>E13307 &amp; 013307</b> <i>Deans</i></p>
	<p><b>LCK039</b> LH LATCH BLACK CATCH</p>	<p><b>215529</b> <i>Deans</i></p>
	<p><b>LCK040</b> RH LATCH BLACK CATCH</p>	<p><b>215656</b> <i>Deans</i></p>



	<p><b>NUTSP-05</b> CHROME 1/2" STARLOCK WASHER</p>	<p><b>044066</b> <i>Deans</i></p>
	<p><b>RLR002A</b> 25mm NYLON ROLLER FOR BOTTOM BEARING</p>	<p><b>E22156</b> <i>Deans</i></p>
	<p><b>RLR003A</b> 32mm NYLON ROLLER FOR DEANS BOTTOM BEARING</p>	<p><b>026437</b> <i>Deans</i></p>
	<p><b>RLR005A</b> 32mm NYLON ROLLER FOR DEANS SPINDLES</p>	<p><b>E32682</b> <i>Deans</i></p>
	<p><b>BUT013A</b> BUTTON MICROSWITCH ELECTRIC</p>	<p><b>024876</b> <i>Deans</i></p>
 <p><b>ELE022</b></p>	<p><b>ELE022A</b> OMRON V15-1C5 MICROSWITCH</p>	<p><b>026752</b> <i>Deans</i></p>
	<p><b>DS-049160</b> BRUSH CARRIER ARRANGEMENT</p>	<p><b>049160</b> <i>Deans</i></p>

	<p><b>PLG005</b> 5DIA NYLON PLUG - DEANS KKT</p>	<p><b>100603</b> <i>Deans</i></p>
	<p><b>PLT063</b> PS GUIDE CHANNEL COVER</p>	<p><b>H101668</b> <i>Deans</i></p>
 <p><b>RUB034</b></p>	<p><b>RUB034</b> RUBBER GROMMET DOOR STOP</p>	<p><b>F02219</b> <i>Deans</i> <b>75F2219</b> <i>Deans</i></p>
	<p><b>RUB200</b> 64mm APERTURE SEAL</p>	<p><b>026414</b> <i>Deans</i></p>
 <p><b>RUB201</b></p>	<p><b>RUB201</b> RUBBER BOOT LOWER PIVOT</p>	<p><b>025444</b> <i>Deans</i></p>
 <p><b>RUB202</b></p>	<p><b>RUB202</b> PLAIN NOSING RUBBER 2.1m</p>	<p><b>031176</b> <i>Deans</i></p>
 <p><b>RUB203</b></p>	<p><b>RUB203</b> LIP NOSING RUBBER 2.1m</p>	<p><b>031177</b> <i>Deans</i></p>

 <p><b>RUB204</b></p>	<p><b>RUB204</b> LOWER VANE SEAL</p>	<p><b>041462</b> Deans</p>
	<p><b>RUB210</b> POSITIVE SEAL ASSY LH <b>RUB212</b> POSITIVE SEAL ASSY RH</p>	<p><b>H104521</b> Deans <b>H104522</b> Deans (ADL E400)</p>
	<p><b>RUB220</b> POSITIVE SEAL ASSY LH <b>RUB221</b> POSITIVE SEAL ASSY RH</p>	<p><b>H109172</b> Deans <b>H109173</b> Deans (ADL E300)</p>
	<p><b>RUB238</b> POSITIVE SEAL ASSY LH <b>RUB239</b> POSITIVE SEAL ASSY RH</p>	<p><b>H106702</b> Deans <b>H106703</b> Deans (ADL E200)</p>
 <p><b>RUB211</b></p>	<p><b>RUB211</b> COVER SEAL</p>	<p><b>043021</b> Deans</p>
	<p><b>RUB224</b> DRAUGHT SEALING BAND</p>	<p><b>C25268</b> Deans</p>
	<p><b>RUB225</b> ACTIVE FLAP/POSITIVE SEAL RUBBER PROFILE</p>	<p><b>H102089</b> Deans</p>

	<p><b>RUB228RH-366</b> RH ACTIVE FLAP ASSY</p>	<p><b>043018</b> Deans</p>
	<p><b>RUB252</b> KKT PLUG SLIDER COMPRESS EDGE NOSING RUBBER (2300MM)  # SEE SENS EDGE BUNG RUB256</p>	<p><b>C100254</b> Deans</p>
	<p><b>RUB254</b> DEANS PS U FRAME SEAL (2.2MTR)</p>	<p><b>0100234</b> Deans</p>
	<p><b>RUB255</b> DEANS KIEKERT FRAME CAPPING SEAL</p>	<p><b>D49812</b> Deans</p>
	<p><b>RUB256</b> RUBBER BUNG KEIKERT DOOR NOSING RUBBERS (SENS EDGE)  # SEE NOSING RUBBER RUB252</p>	<p><b>E100237</b> Deans</p>
	<p><b>SAB043</b> DEANS NO.2 RH BOTTOM BRUSH BOX ASSY</p>	<p><b>049567</b> Deans</p>
	<p><b>SAB044</b> DEANS NO.1 LH BOTTOM BRUSH BOX ASSY</p>	<p><b>049566</b> Deans</p>

	<p><b>SAB544RH-01</b> RH STEEL SABOT ASSY SAB. (L=544. D=82 H=86)</p> <p><b>SAB544LH-01</b> LH STEEL SABOT ASSY SAB. (L=544. D=82. H=86)</p>	<p><b>035813, 033846</b> <i>Deans</i></p> <p><b>035814, 033847</b> <i>Deans</i> ADJUSTABLE BRS 49 to 62</p>
	<p><b>SAB571RH-01</b> RH STEEL SABOT ASSY SAB. (L=571 D=24 H=68)</p> <p><b>SAB571LH-01</b> LH STEEL SABOT ASSY SAB. (L=571 D=24 H=68)</p>	<p><b>032545</b> <i>Deans</i></p> <p><b>032546</b> <i>Deans</i> (OPTARE SOLO FF) ADJUSTABLE BRS 70 to 82 41 to 53</p>
	<p><b>SCR009</b> WOODRUFF KEY - 0102432</p>	<p><b>0102432</b> <i>PETERS</i></p>
	<p><b>HDL001A</b> GRAB HANDLE BLACK POLYAMIDE</p>	<p><b>027645</b> <i>Deans</i></p>
	<p><b>HDL003A</b> PRIMARY EMERGENCY RELEASE</p>	<p><b>8F071169</b> <i>Deans</i></p>
	<p><b>HDL033</b> HAND GRIP - DEANS PS</p>	<p><b>024708</b> <i>Deans</i></p>



	<p><b>HDL034</b> HANDLE</p>	<p><b>068000</b> <i>Deans</i></p>
	<p><b>HDL044</b> SLIMLINE RECESSED HANDLE</p>	<p><b>0102268</b> <i>Deans</i></p>
 <p>KIT019</p>	<p><b>KIT019</b> HANDRAIL FIXING KIT - DEANS</p>	<p><b>072028</b> <i>Deans</i></p>
	<p><b>PLT100B</b> SEAL RETAINING PLATE 2200x20 BLACK <b>PLT100-1340</b> SEAL RETAINING PLATE 1340x20 BLACK</p>	<p><b>Retainer for Seals &gt;</b> <b>026414</b> <i>Deans</i> <b>215575</b> <i>Peters</i> + Other similar applications</p>
	<p><b>SPA007</b> DEANS BRACKET SPACER</p>	<p><b>H102218</b> <i>Deans</i></p>
	<p><b>SPA027</b> ALUM M8 SPACER</p>	<p><b>H101626</b> <i>Deans</i></p>
	<p><b>RUB215</b> UPVC GLAZING SECTION 2500L</p>	<p><b>H030498</b> <i>Deans</i></p>



**RUB216**  
DOOR GLAZING STRIP 2500L

**H030499** *Deans*