

**TDS PRODUCT IMAGE SHEET – CATEGORY >  
BRUSHES/RUBBER SEALS-GASKETS**

| <b>Images</b>   | <b>TDS Part Number &amp; Description</b>   | <b>OE &amp; Alternative Part References<br/>(WHERE FITTED)</b>  |
|---|--|---|
|    | <p><b>BRS001</b><br/>25mm NYLON BRUSH<br/>(CUT TO SIZE – UPTO 3MTR)</p>  | <p><b>205436</b> Peters</p>   |
|    | <p><b>BRS003</b><br/>38mm NYLON BRUSH<br/>(CUT TO SIZE – UPTO 3MTR)</p>  | <p><b>205428</b> Peters</p>   |
|   | <p><b>BRS005</b><br/>51mm NYLON BRUSH<br/>(CUT TO SIZE – UPTO 3MTR)</p>  | <p><b>205431</b> Peters</p>   |
|  | <p><b>BRS007</b><br/>64mm NYLON BRUSH<br/>(CUT TO SIZE – UPTO 2.5MTR)</p>  | <p><b>205433</b> Peters</p>   |
|  | <p><b>BRS009+10</b><br/>76+80mm NYLON BRUSH</p>  | <p><b>205435</b> Peters</p>   |
|  | <p><b>BSA Holder Assys</b><br/>BLACK RIGID PVC HOLDERS<br/>AVAILABLE WITH ANY<br/>BRUSH/SIZE/FORM<br/>COMBINATION AS REQD</p> <p>SUITABLE FOR &gt;</p> <ul style="list-style-type: none"> <li>• DRILLING</li> <li>• NOTCHING</li> <li>• BENDING</li> <li>• FORMING</li> </ul> <p>&lt;&lt; SEE PICTURE FOR EXAMPLES</p> | <p>Part Number Key:<br/><b>BSA**07-****-01</b><br/>TDS, Ventura, Deans,<br/>Peters, Overton-Percy Lane<br/>Example:<br/><b>BSA6407-1200-01</b><br/>Brush &amp; holder Assy<br/>with 64mm Bristle,<br/>Cut To1200mm long</p> |

|   |   |  |
|---|---|--|
|    | <p><b>EXT007C</b><br/>BRUSH HOLDER BLACK<br/>RIGID PVC 3MTR LENGTH</p>              | <p><b>EXT007C</b> TDS</p>                        |
|    | <p><b>DS-049160</b><br/>DEANS CARRIER BRUSH<br/>ARRANGEMENT</p>                     | <p><b>049160</b> TDS</p>                         |
|    | <p><b>CAP016</b><br/>NEOPRENE CAP – 1/2"<br/>WILL FIT OVER M12 HEX HD<br/>SCREW</p> | <p><b>046458</b> Deans</p>                       |
|   | <p><b>CAP017</b><br/>NEOPRENE CAP – 5/16"<br/>WILL FIT OVER M8 HEX HD<br/>SCREW</p> | <p>TDS</p>                                       |
|  | <p><b>STP002</b><br/>M6x20(16)<br/>RUBBER STOP</p>                                  | <p>TDS</p>                                       |
|  | <p><b>STP003</b><br/>M10x60(25)<br/>RUBBER STOP</p>                                 | <p>TDS</p>                                       |
|  | <p><b>STP004</b><br/>M8x60(22)<br/>RUBBER STOP</p>                                  | <p>TDS</p>                                       |
|  | <p><b>STP012</b><br/>M16x90(22)<br/>RUBBER STOP</p>                                 | <p><b>H102289</b> Deans<br/>USED ON DEANS PS</p> |

|   |  |   |
|---|--|---|
|    | <p><b>GAS001</b><br/>EXTERNAL EMERGENCY OPEN<br/>BUTTON GASKET</p>   | <p><b>GAS001</b> TDS</p>  |
|    | <p><b>PLT100B</b><br/>SEAL RETAINING PLATE<br/>2200x20 BLACK<br/><b>PLT100-1340</b><br/>SEAL RETAINING PLATE<br/>1340x20 BLACK</p> | <p><b>Retainer for Seals &gt;</b><br/><b>026414</b> Deans<br/><b>215575</b> Peters<br/>+ Other similar applications</p> |
|    | <p><b>ATF1-###-##</b><br/>WIDTH – SEAL (mm)<br/>BOTTOM ACTIVE FLAP ASSYS<br/><br/>EXAMPLE &gt; ATF1-598-35</p>                     | <p><b>ATF1-###-##</b> TDS<br/>(ALL TDS GLIDER DOORS,<br/>SIZE DOOR SPECIFIC )</p>                                       |
|  | <p><b>RUB002A</b><br/>VEHICLE APERTURE PLAIN SEAL<br/>50mm x 2.5MTR</p>  | <p><b>215575</b> Peters<br/><b>RUB002A</b> TDS</p>  |
|  | <p><b>RUB004A</b><br/>TRAILING EDGE CAPPING SEAL<br/>38mm PUSH-IN</p>  | <p><b>RUB004A</b> TDS</p>   |
|  | <p><b>RUB005A</b><br/>INNER GLAZING SEAL<br/>(MIN 10MTR)</p>   | <p><b>RUB005A</b> TDS</p>   |
|  | <p><b>RUB006A</b><br/>LEADING EDGE LIPPED NOSING<br/>RUBBER 38x62 – 2.3MTR</p>   | <p><b>RUB006A</b> TDS</p>   |

|   |  |  |
|---|--|--|
|    | <p><b>RUB009A</b><br/>UPPER GLASS EDGING RUBBER<br/>(MIN 10MTR)</p>                          | <p><b>RUB009A</b> TDS</p>                              |
|    | <p><b>RUB011A</b><br/>VEHICLE APERTURE LIPPED SEAL<br/>50x50<br/><br/>(2200L APR20 &gt;)</p> | <p><b>RUB011A</b> TDS<br/>(TREKA 16 - TDS GLIDERS)</p> |
|    | <p><b>RUB012</b><br/>LOWER GLASS EDGING RUBBER<br/>(MIN 10MTR)</p>                           | <p><b>RUB012</b> TDS</p>                               |
|   | <p><b>RUB013B</b><br/>68x3 INSERTION RUBBER STRIP<br/>(10MTR COIL)</p>                       | <p><b>216368</b> Peters</p>                            |
|  | <p><b>RUB013B-75</b><br/>D/SHAFT RUBBER SEAL 75x68</p>                                       | <p><b>216213</b> Peters</p>                            |
|  | <p><b>RUB015B</b><br/>150x3 INSERTION RUBBER STRIP<br/>(10MTR COIL)</p>                      | <p><b>215966/7</b> Peters</p>                          |
|  | <p><b>RUB018B</b><br/>150x1.5 INSERTION RUBBER STRIP<br/>(10MTR COIL)</p>                    | <p><b>RUB018B</b> TDS</p>                              |



|   |   |   |
|---|---|---|
|                  | <p><b>RUB023A</b><br/>MALE HINGE SEAL<br/>38x21 – 2.3MTR</p>                          | <p><b>RUB023A</b> TDS</p>                           |
|                  | <p><b>RUB025A</b><br/>TRAILING EDGE SHORT LIPPED<br/>NOSING RUBBER 38x52 – 2.3MTR</p> | <p><b>RUB025A</b> TDS</p>                           |
|  <p>RUB027</p>   | <p><b>RUB027</b><br/>NOSING RUBBER BUNG FOR<br/>SENSITIVE EDGE SEALING</p>            | <p><b>RUB027</b> TDS</p>                            |
|  <p>RUB033</p> | <p><b>RUB033</b><br/>EURO RUBBER FOAM BUNG</p>  | <p><b>216125</b> Peters</p>                         |
|  <p>RUB034</p> | <p><b>RUB034</b><br/>RUBBER GROMMET DOOR STOP</p>                                     | <p><b>F02219</b> Deans<br/><b>75F2219</b> Deans</p> |
|                | <p><b>RUB044A</b><br/>VEHICLE APERTURE "T" SEAL<br/>56-58mm x 2.5MTR</p>              | <p><b>RUB044A</b> TDS</p>                           |

|   |  |  |
|---|--|--|
|    | <p><b>NEW</b><br/><b>RUB045</b><br/><b>RUBBER BOOT</b><br/>FOR (TRACK) ROD ENDS</p>                          | <p><b>For Plug Door pivot arms.</b><br/><b>See also</b><br/>BRG073<br/>BRK070-28<br/>SAB040</p>  |
|    | <p><b>NEW</b><br/><b>RUB046-01</b><br/><b>BUTTON BOOT</b><br/>CAN BE CUT TO SUIT ALL<br/>BUTTON VARIANTS</p> | <p><b>RUB046-01</b> TDS</p>   |
|    | <p><b>RUB051</b><br/>"D" ADHESIVE BACK FOAM SEAL<br/>10x12x2</p>   |  |
|   | <p><b>RUB053-1976-L2</b><br/>(E40 SENS LONG LIP RUB ASSY)</p>  | <p><b>RUB053</b> TDS</p>   |
|  | <p><b>RUB054-1976-R2</b><br/>(E40 SENS SHORT LIP RUB ASSY)</p>   | <p><b>RUB054</b> TDS</p>   |
|  | <p><b>RUB058</b><br/>STEP INSERT TIGER STRIPE</p>  | <p><b>RUB058</b> TDS</p>   |
|  | <p><b>RUB102</b><br/>LIPPED NOSING RUBBER<br/>PDS EURODOOR</p>   | <p><b>215709</b> Peters</p>  |

|   |   |                                    |
|---|---|------------------------------------|
|    | <p><b>RUB103</b><br/>PLAIN NOSING RUBBER<br/>PDS EURODOOR</p> | <p><b>215710</b> <i>Peters</i></p> |
|    | <p><b>RUB122-KIT</b><br/>OUTER SEAL FLAP KIT</p>              | <p><b>215820</b> <i>Peters</i></p> |
|    | <p><b>RUB123-KIT</b><br/>OUTER SEAL FLAP KIT</p>              | <p><b>216394</b> <i>Peters</i></p> |
|   | <p><b>RUB124-KIT</b><br/>OUTER SEAL FLAP KIT</p>              | <p><b>216155</b> <i>Peters</i></p> |
|  | <p><b>RUB124-FLP</b><br/>SEAL FLAP ONLY</p>                   | <p><b>216156</b> <i>Peters</i></p> |
|  | <p><b>RUB125-KIT</b><br/>OUTER SEAL FLAP KIT</p>              | <p><b>216357</b> <i>Peters</i></p> |

|  |   |                                    |
|--|---|------------------------------------|
|  | <p><b>RUB129</b><br/>40mm SNAP ON SEAL</p>                  | <p><b>214359</b> <i>Peters</i></p> |
|  | <p><b>RUB200</b><br/>64mm APERTURE SEAL</p>                 | <p><b>026414</b> <i>Deans</i></p>  |
|  | <p><b>RUB201</b><br/>RUBBER BOOT LOWER PIVOT</p>            | <p><b>025444</b> <i>Deans</i></p>  |
|  | <p><b>RUB202</b><br/>PLAIN NOSING RUBBER 2.1m<br/>71x30</p> | <p><b>031176</b> <i>Deans</i></p>  |
|  | <p><b>RUB203</b><br/>LIP NOSING RUBBER 2.1m<br/>71x30</p>   | <p><b>031177</b> <i>Deans</i></p>  |
|  | <p><b>RUB204</b><br/>LOWER VANE SEAL<br/>38 x 482</p>       | <p><b>041462</b> <i>Deans</i></p>  |



|   |  |   |
|---|--|---|
|    | <p><b>RUB209</b><br/>ACTIVE VANE SEAL<br/>106 x 493</p>  | <p><b>041460</b> <i>Deans</i></p>   |
|    | <p><b>RUB210</b><br/>LH POSITIVE SEAL ASSY 569mm<br/>No.1 DOOR<br/><b>RUB212</b><br/>RH POSITIVE SEAL ASSY 569mm<br/>No.2 DOOR</p>                           | <p><b>H104521</b> <i>Deans</i><br/><b>H104522</b> <i>Deans</i><br/>(ADL E400)</p> |
|    | <p><b>RUB220</b><br/>LH POSITIVE SEAL ASSY 522mm<br/>No1 DOOR<br/><b>RUB221</b><br/>RH POSITIVE SEAL ASSY 522mm<br/>No.2 Door</p>                            | <p><b>H109172</b> <i>Deans</i><br/><b>H109173</b> <i>Deans</i><br/>(ADL E300)</p> |
|   | <p><b>RUB238</b><br/>LH POSITIVE SEAL ASSY 471mm<br/>No.1 DOOR FROM OUTSIDE<br/><b>RUB239</b><br/>RH POSITIVE SEAL ASSY 471mm<br/>No.2 DOOR FROM OUTSIDE</p> | <p><b>H106702</b> <i>Deans</i><br/><b>H106703</b> <i>Deans</i><br/>(ADL E200)</p> |
|  | <p><b>RUB248</b><br/>RH POSITIVE SEAL ASSY 538mm.<br/>C=225 FROM RIGHT TO LEFT<br/>No.2 DOOR FROM OUTSIDE</p>  | <p><b>H108753</b> <i>Deans</i><br/>OPTARE Volvo B9 "Visionaire"</p>               |
|  | <p><b>RUB249</b><br/>LH POSITIVE SEAL ASSY 538mm<br/>C=225 FROM LEFT TO RIGHT<br/>No.1 DOOR FROM OUTSIDE</p>   | <p><b>H108752</b> <i>Deans</i><br/>OPTARE Volvo B9 "Visionaire"</p>               |
|  | <p><b>RUB211</b><br/>COVER SEAL</p>  | <p><b>043021</b> <i>Deans</i></p>   |

|   |   |  |
|---|---|--|
|    | <p><b>RUB215</b><br/>UPVC GLAZING SECTION 2500L</p>                   | <p><b>032605 (D030498)</b><br/><i>Deans</i></p>  |
|    | <p><b>RUB216</b><br/>DOOR GLAZING STRIP 2500L</p>                     | <p><b>032606 (D030499)</b><br/><i>Deans</i></p>  |
|   | <p><b>RUB224</b><br/>DRAUGHT SEALING BAND</p>                         | <p><b>C25268</b> <i>Deans</i></p>  |
|  | <p><b>RUB225</b><br/>ACTIVE FLAP/POSITIVE SEAL<br/>RUBBER PROFILE</p> | <p><b>H102089</b> <i>Deans</i></p>   |
|  | <p><b>RUB228LH-366</b><br/>LH ACTIVE FLAP ASSY<br/>No.1 DOOR</p>      | <p><b>043017</b> <i>Deans</i></p>  |
|  | <p><b>RUB228RH-366</b><br/>RH ACTIVE FLAP ASSY<br/>No.2 DOOR</p>      | <p><b>043018</b> <i>Deans</i></p>  |

|   |  |  |
|---|--|--|
|    | <p><b>RUB252</b><br/>KKT PLUG SLIDER COMPRESS EDGE<br/>NOSING RUBBER (2300MM)</p> <p># SEE SENS EDGE BUNG RUB256</p> | <p><b>C100254</b> <i>Deans</i></p>                         |
|    | <p><b>RUB254</b><br/>DEANS PS U FRAME SEAL (2.2MTR)</p>  | <p><b>0100234</b> <i>Deans</i></p>                         |
|    | <p><b>RUB255</b><br/>DEANS CAPPING SEAL</p>  | <p><b>D49812</b> <i>Deans</i></p>                          |
|  | <p><b>RUB256</b><br/>RUBBER BUNG KEIKERT DOOR<br/>NOSING RUBBERS (SENS EDGE)</p> <p># SEE NOSING RUBBER RUB252</p>   | <p><b>E100237</b> <i>Deans</i></p>                         |
|  | <p><b>RUB257</b><br/>Cover – Rubber Boot [Door<br/>Motor/Arm Assy]</p>   | <p><b>B104012</b> <i>BCE</i></p>                           |
|  | <p><b>B768</b><br/>END RUBBER PROFILE IG3</p>  | <p><b>B768</b> <i>Ventura</i></p>                          |
|  | <p><b>C449</b><br/>EDGE PROTECTION RUBBER</p>  | <p><b>C449</b> <i>Ventura</i><br/><b>WRIGHTBUS IG4</b></p> |

|   |   |  |
|---|---|--|
|    | <p><b>C449-100</b><br/>EDGE PROTECTION RUBBER</p>                       | <p><b>C449-100</b> <i>Ventura</i><br/><b>WRIGHTBUS IG4</b></p> |
|    | <p><b>C670</b><br/>GLASS SEALING TAPE 3x9 BLACK</p>                     | <p><b>C670</b> <i>Ventura</i></p>                              |
|   | <p><b>D251-002</b><br/>PS U-FRAME RUBBER PROFILE<br/>TOP &amp; SIDE</p> | <p><b>D251-002</b> <i>Ventura</i></p>                          |
|  | <p><b>D273-001</b><br/>DOOR SEAL MIDDLE (PS)<br/>2200L NO CUTOUT</p>    | <p><b>D273-001</b> <i>Ventura</i></p>                          |
|  | <p><b>D273-002</b><br/>DOOR SEAL MIDDLE (PS)<br/>2200L LEFT CUTOUT</p>  | <p><b>D273-002</b> <i>Ventura</i></p>                          |
|  | <p><b>D273-003</b><br/>DOOR SEAL MIDDLE (PS)<br/>2200L RIGHT CUTOUT</p> | <p><b>D273-003</b> <i>Ventura</i></p>                          |



|   |  |   |
|---|--|---|
|    | <p><b>D325</b><br/>CUSHIONING RUBBER RING 6mm</p>              | <p><b>D325</b> <i>Ventura</i></p>                                     |
|    | <p><b>D337-001</b><br/>PORTAL SEAL</p>                         | <p><b>D337-001</b> <i>Ventura</i></p>                                 |
|   | <p><b>D373</b><br/>BRUSH HOLDER ASSY<br/>544x50 PREDRILLED</p> | <p><b>D373</b> <i>Ventura</i><br/>WRIGHTBUS GEMINI DD PS</p>          |
|  | <p><b>D672</b><br/>BRUSH HOLDER ASSY<br/>523x23 PREDRILLED</p> | <p><b>D672</b> <i>Ventura</i><br/>ADL E200 PS, WB NBFL PS</p>         |
|  | <p><b>E251</b><br/>SQUARE RUBBER PIECE</p>                     | <p><b>E251</b> <i>Ventura</i><br/>WRIGHTBUS PS2, NBFL PS, NFBL RS</p> |
|  | <p><b>F425</b><br/>BRUSH HOLDER ASSY<br/>564x73 PREDRILLED</p> | <p><b>F425</b> <i>Ventura</i><br/>WRIGHTBUS ECLIPSE SD PS</p>         |

|   |  |   |
|---|--|---|
|    | <p><b>F597</b><br/>DOORSEAL MIDDLE (IG)<br/>2200mm</p>   | <p><b>F597</b> <i>Ventura</i></p>   |
|    | <p><b>F629</b><br/>FLAP BOTTOM RUBBER (IG)</p>   | <p><b>F629</b> <i>Ventura</i><br/>ALL IG4 FLAPS</p>   |
|   | <p><b>F629-002</b><br/>FLAP RUBBER L=600</p>   | <p><b>F629-002</b> <i>Ventura</i><br/>WRIGHTBUS STREETLITE IGE</p>  |
|  | <p><b>F858</b><br/>PORTAL RUBBER U-FRAME F617<br/>OMNI</p>   | <p><b>F858</b> <i>Ventura</i><br/>POLISH SCANIA OMNICITY DD IG3</p>   |
|  | <p><b>F904</b><br/>BRUSH WITH HOLES L=499mm</p>  | <p><b>F904</b> <i>Ventura</i><br/>WRIGHTBUS ECLIPSE SD PS.<br/>POLISH SCANIA OMNI CITY PS.<br/>LH &amp; RH DOORS</p>    |
|  | <p><b>G397</b><br/>D251-U FRAME H1815W564<br/>(LH DOOR LEAF J475)</p> <p>NOTE OPPOSITE HAND AND ALL<br/>OTHER DOOR VARIANTS<br/>AVAILABLE ON ENQUIRY</p> | <p><b>G397</b> <i>Ventura</i><br/>WRIGHTBUS GEMINI SD</p> <p>NOTE ALL OTHER VEHICLE MODELS<br/>AVAILABLE ON ENQUIRY</p> |

|   |   |   |
|---|---|---|
|    | <p><b>G446</b><br/>FLAP TOP RUBBER (IG)</p>   | <p><b>G446</b> <i>Ventura</i></p>   |
|    | <p><b>G952-012</b><br/>PORTAL SEAL RS</p>   | <p><b>G952-012</b> <i>Ventura</i><br/>BLUEBIRD SD RS</p>  |
|   | <p><b>H446-001</b><br/>PORTAL SEAL TOP – 1600L<br/>(I032, J165 PORTAL ASSY)</p>                               | <p><b>H446-001</b> <i>Ventura</i><br/>(ADL E400 DD IG3, POLISH SCANIA<br/>OMNICITY IG3 JAN08&gt;)</p>   |
|  | <p><b>H452-001</b><br/>PORTAL SEAL SIDE – 2200L<br/>(I032, J165, K092, K093, K095, K526<br/>PORTAL ASSYS)</p> | <p><b>H452-001</b> <i>Ventura</i><br/>(ADL E400 DD IG3, WRIGHTBUS<br/>GEMINI DD IG4, EAST LANCS SD IG3 +<br/>OLYMPUS DD IG3,<br/>WRIGHTBUS NBFL DD IG4, POLISH<br/>SCANIA OMNICITY IG3 JAN08&gt;)</p> |
|  | <p><b>I032</b><br/>PORTAL RUBBER U PROFILE 1350</p>   | <p><b>I032</b> <i>Ventura</i><br/>ADL E400 DD IG3</p>   |


|   |   |   |
|---|---|---|
|    | <p><b>J163-001</b><br/>PORTAL SEAL SIDE – 2350L<br/><br/>(I694,J205,J462,J469<br/>PORTAL ASSYS)</p> | <p><b>J163-001</b> <i>Ventura</i><br/>(ADL E400 DD IG3, ADL E300 SD IG4 +<br/>E400 DD IG4, ADL E200 SD IG4)</p> |
|    | <p><b>J164-001</b><br/>PORTAL SEAL TOP – 1600L<br/><br/>(I694,J205,J462,J469<br/>PORTAL ASSYS)</p>  | <p><b>J164-001</b> <i>Ventura</i><br/>(ADL E400 DD IG3, ADL E300 SD IG4 +<br/>E400 DD IG4, ADL E200 SD IG4)</p> |
|    | <p><b>I694</b><br/>PORTAL RUBBER U PROFILE 1425</p>   | <p><b>I694</b> <i>Ventura</i><br/>(ADL E400 DUBLIN)</p>   |
|   | <p><b>J205</b><br/>PORTAL RUBBER U PROFILE 1350</p>   | <p><b>J205</b> <i>Ventura</i><br/>ADL E300 SD IG4 + E400 DD IG4</p>   |
|  | <p><b>J462</b><br/>PORTAL RUBBER U PROFILE 1200</p>   | <p><b>J462</b> <i>Ventura</i><br/>ADL E200 SD IG4</p>   |
|  | <p><b>J469</b><br/>PORTAL RUBBER U PROFILE 1290</p>   | <p><b>J469</b> <i>Ventura</i><br/>ADL E300 SD IG3/IG4 + E400 DD IG4</p>   |
|  | <p><b>J684</b><br/>SUPERSEAL TOP BRUSH<br/>(F416-1500)</p>  | <p><b>J684</b> <i>Ventura</i><br/>ADL E400 PS</p>   |



|                                 |   |   |
|---------------------------------|---|---|
|                                 | <p><b>K092</b> (H506)<br/>PORTAL RUBBER U PROFILE 1290</p>  | <p><b>K092</b> <i>Ventura</i><br/>WRIGHTBUS ECLIPSE SD IG3 + GEMINI DD IG3, EAST LANCS SD IG3<br/>WRIGHTBUS GEMINI DD IG4, EAST LANCS SD IG3 + OLYMPUS DD IG3, WRIGHTBUS ECLIPSE SD IG4</p> |
|                                 | <p><b>K093</b> (J165)<br/>PORTAL RUBBER U PROFILE 1200</p>  | <p><b>K093</b> <i>Ventura</i><br/>POLISH SCANIA OMNICITY (JAN08 &gt;)</p>   |
| <p>Views vulcanized corners</p> | <p><b>K095</b><br/>PORTAL RUBBER U PROFILE 1250 (HESS)</p>  | <p><b>K095</b> <i>Ventura</i><br/>WRIGHTBUS NBFL DD IG4</p>   |
|                                 | <p><b>K962-001</b><br/>DOOR SEAL MIDDLE GEN 3<br/>L=2200mm<br/>K962-002 = LEFT CUTOUT<br/>K963-003 = RIGHT CUTOUT<br/><br/># APR17 &gt; REPLACING WITH VA4802</p> | <p><b>K962-001</b> <i>Ventura</i><br/><b>K962-002</b> <i>Ventura</i><br/><b>K962-003</b> <i>Ventura</i><br/>ALL PS2</p>   |
|                                 | <p><b>K963-001</b> (U255)<br/>DOOR SEAL GEN3 L=2200mm (UFRAME SIDE/TOP)</p>   | <p><b>K963-001</b> <i>Ventura</i><br/>ALL PS2</p>   |
|                                 | <p><b>L336-001</b><br/>PORTAL SEAL TOP – 1600L<br/><br/># USED ON L781,M442,M650 PORTAL SEAL ASSYS</p>  | <p><b>L336-001</b> <i>Ventura</i><br/>MCV SD 112/124RLE/DD EVOSETI IG4, TEMSA SD IG4</p>  |
|                                 | <p><b>L337-001</b><br/>PORTAL SEAL SIDE – 2500L<br/><br/># USED ON L781,M442,M650 PORTAL SEAL ASSYS</p>   | <p><b>L337-001</b> <i>Ventura</i><br/>MCV SD 112/124RLE/DD EVOSETI IG4, TEMSA SD IG4</p>  |

|   |  |  |
|---|--|--|
|  <p>Center line of side and opposite profiles to be connected. Mounting should be done before. Radius of frame, should be increased stress.</p>                  | <p><b>L781</b><br/>PORTAL RUBBER U-FRAME 1350<br/># PROFILES VERT = L337-001,<br/>HORZ = L336-001)</p>           | <p><b>L781</b> <i>Ventura</i><br/>MCV SD 112/124RLE/DD EVOSETI<br/>IG4, TEMSA SD IG4</p> |
|    | <p><b>M298</b><br/>PORTAL SEAL IG TOP</p>  | <p><b>M298</b> <i>Ventura</i><br/>WRIGHTBUS STREETLIE / EURO6 IG4</p>                    |
|    | <p><b>M299</b><br/>PORTAL SEAL IG SIDE L-2200</p>  | <p><b>M299</b> <i>Ventura</i><br/>WRIGHTBUS STREETLIE / EURO6 IG4</p>                    |
|  <p>(1:1) (1:1)<br/>Center line of side and opposite profiles to be connected. Mounting should be done before. Radius of frame, should be increased stress.</p> | <p><b>M300</b><br/>PORTAL RUBBER U PROFILE 1290<br/>(HESS) MIDI<br/># PROFILES VERT = M299,<br/>HORZ = M298)</p> | <p><b>M300</b> <i>Ventura</i><br/>WRIGHTBUS STREETLIE / EURO6 IG4</p>                    |
|  <p>Center line of side and opposite profiles to be connected. Mounting should be done before. Radius of frame, should be increased stress.</p>                | <p><b>M442</b><br/>PORTAL U-FRAME IG 1290<br/># PROFILES VERT = L337-001,<br/>HORZ = L336-001)</p>               | <p><b>M442</b> <i>Ventura</i><br/>MCV SD 112/124RLE IG4<br/>EVORA</p>                    |
|    | <p><b>N010</b><br/>RUBBER COVERPLATE</p>   | <p><b>N010</b> <i>Ventura</i><br/>WRIGHTBUS STREETLITE IGE</p>                           |
|    | <p><b>O430</b><br/>IG4 BRUSH HOLDER ASSY<br/>543x30 PRE-DRILLED NBFL</p>   | <p><b>O430</b> <i>Ventura</i><br/>VENTURA NFBL</p>                                       |
|    | <p><b>O708</b><br/>PORTAL SEAL IG4 WB NBFL DR5</p>   | <p><b>O708</b> <i>Ventura</i></p>  |

|   |   |   |
|---|---|---|
|    | <p><b>R042</b><br/>SEAL VA0155-L 1880</p>   | <p><b>R042</b> <i>Ventura</i><br/>WRIGHTBUS IG4</p>   |
|    | <p><b>R043</b><br/>SEAL VA0155-R 1880</p>   | <p><b>R043</b> <i>Ventura</i><br/>WRIGHTBUS IG4</p>   |
|    | <p><b>S857</b><br/>SEAL P762-OL H1820W564</p>   | <p><b>S857</b> <i>Ventura</i><br/>WRIGHTBUS PS2</p>   |
|    | <p><b>S858</b><br/>SEAL P762-OR H1820W564</p>   | <p><b>S858</b> <i>Ventura</i><br/>WRIGHTBUS PS2</p>   |
|  | <p><b>U446-001</b><br/>PORTAL SEAL TOP 1600 - IG4</p>   | <p><b>U446-001</b> <i>Ventura</i><br/>ADL E200 EV, MMC</p>  |
|  | <p><b>U447-001</b><br/>PORTAL SEAL SIDE 2200 - IG4</p>  | <p><b>U447-001</b> <i>Ventura</i><br/>ADL E200 EV, MMC</p>  |
|  | <p><b>VA0184 / VA0186</b><br/>SEAL VA0115-L 2200 / 2000<br/><b>VA0185 / VA0187</b><br/>SEAL VA0115-R 2200 / 2000</p>          | <p><b>VA0184/VA0186</b><br/><b>VA0185/VA0187</b><br/><i>Ventura</i><br/>ADL E200, WRIGHTBUS NBFL/<br/>STREETLITE, IG4 LATER</p> |
|  | <p><b>VA2287</b><br/>SEAL VA0115-L 1870_8K2<br/><b>VA2288</b><br/>SEAL VA0115-R 1870_8K2<br/><b># ASSY INCL SENS EDGE</b></p> | <p><b>VA2287</b> <i>Ventura</i><br/>WRIGHTBUS STREETLITE IGE</p>  |

|   |   |  |
|---|---|--|
|  | <p><b>VA4802-001</b><br/>DOOR SEAL MIDDLE GEN 4<br/>L=2200mm<br/>VA4802-002 = LEFT CUTOUT<br/>VA04802-003 = RIGHT CUTOUT</p> <p># APR17 &gt; REPLACING K962</p> | <p><b>VA4802-001</b> <i>Ventura</i><br/><b>VA4802-002</b> <i>Ventura</i><br/><b>VA4802-003</b> <i>Ventura</i><br/><b>ALL PS2</b></p> |
|---|---|--|

- Also see [SABOT/COVERS – ABS + STEEL](#) Category Sheets  
For other Peters & Deans internal brush assemblies