

**TDS PRODUCT IMAGE SHEET – CATEGORY > FITTINGS & FIXTURES**

Image	TDS Part Number & Description	OE & Alternative Part References
	<p><b>FIT001A</b> 4mm BLANKING PLUG</p> <p><b>FIT002A</b> 6mm BLANKING PLUG</p> <p><b>FIT057</b> 8mm BLANKING PLUG</p>	<p><b>203197</b> <i>Peters</i></p> <p><b>060005</b> <i>Deans</i></p> <p><b>203198</b> <i>Peters</i></p> <p><b>060051</b> <i>Deans</i></p> <p><b>FIT057</b> <i>TDS</i></p>
	<p><b>FIT003A</b> CONNECTOR Y 4mm SLIM</p>	<p><b>203258</b> <i>Peters</i></p> <p><b>0104644</b> <i>Deans</i></p>
	<p><b>FIT004B</b> 4mm x 1/8" BSP ELBOW</p> <p><b>FIT005B</b> 4mm x 1/4" BSP ELBOW</p> <p><b>FIT006B</b> 6mm x 1/8" BSP ELBOW</p> <p><b>FIT007B</b> 6mm x 1/4" BSP ELBOW</p> <p><b>FIT008B</b> 8mm x 1/8" BSP ELBOW</p> <p><b>FIT009B</b> 8mm x 1/4" BSP ELBOW</p>	<p><b>203403</b> <i>Peters</i></p> <p><b>203404</b> <i>Peters</i></p> <p><b>203405</b> <i>Peters</i></p> <p><b>060017</b> <i>Deans</i></p> <p><b>170081</b> <i>Deans</i></p> <p><b>203406</b> <i>Peters</i></p> <p><b>030534</b> <i>Deans</i></p> <p><b>060011</b> <i>Deans</i></p> <p><b>203407</b> <i>Peters</i></p> <p><b>203408</b> <i>Peters</i></p>

	<p><b>FIT010A</b> 8mm x 1/4" BSP MALE STUD</p>	<p><b>203675</b> <i>Peters</i> <b>060034</b> <i>Deans</i></p>
	<p><b>FIT011B</b> 6mm x 1/4" BSP MALE STUD</p>	<p><b>203677</b> <i>Peters</i> <b>060003</b> <i>Deans</i></p>
	<p><b>FIT012B</b> 4mm x 1/8" BSP MALE STUD</p>	<p><b>203678</b> <i>Peters</i></p>
	<p><b>FIT013B</b> 6mm x 1/8" BSP MALE STUD</p>	<p><b>203679</b> <i>Peters</i></p>
	<p><b>FIT032B</b> 8mm x 1/8" BSP MALE STUD</p>	<p><b>FIT032B</b> <i>TDS</i></p>
	<p><b>FIT079B</b> 4mm x M5 MALE STUD</p>	<p><b>FIT079B</b> <i>TDS</i></p>
 <p><b>FIT014A</b></p>	<p><b>FIT014A</b> 4mm x 1/8" BSP FEMALE STUD</p>	<p><b>203681</b> <i>Peters</i></p>
	<p><b>FIT033A</b> 8mm x 1/4" BSP FEMALE STUD</p>	<p><b>FIT033A</b> <i>TDS</i></p>
	<p><b>FIT034A</b> 6mm x 1/4" BSP FEMALE STUD</p>	<p><b>FIT034A</b> <i>TDS</i></p>
	<p><b>FIT015B</b> 6mm EQUAL TEE</p>	<p><b>203731</b> <i>Peters</i> <b>060010</b> <i>Deans</i> <b>C363</b> <i>Ventura</i></p>
	<p><b>FIT016B</b> 4mm EQUAL TEE</p>	<p><b>203732</b> <i>Peters</i> <b>060009</b> <i>Deans</i> <b>A751</b> <i>Ventura</i></p>

 <p><b>FIT019B</b></p>	<p><b>FIT019B</b> 6mm MALE 4mm FEMALE REDUCER</p>	<p><b>203754</b> <i>Peters</i> <b>060052</b> <i>Deans</i> <b>H909</b> <i>Ventura</i></p>
	<p><b>FIT020A</b> 8mm TO 6mm REDUCER</p>	<p><b>203755</b> <i>Peters</i></p>
	<p><b>FIT023T-01</b> ELBOW TAIL PIECE 4M-6F</p>	<p><b>215887</b> <i>Peters</i></p>
	<p><b>FIT025B</b> CONNECTOR STRAIGHT 4mm EQUAL <b>FIT031B</b> CONNECTOR STRAIGHT 6mm EQUAL</p>	<p><b>215891</b> <i>Peters</i> <b>FIT031B</b> <i>TDS</i></p>
 <p><b>FIT026B</b></p>	<p><b>FIT026B</b> M5 x 4MM PUSH IN ELBOW</p>	<p><b>216993-28</b> <i>Peters</i></p>
	<p><b>FIT028C</b> 1/8" BSP (PARALLEL THREAD) SOC CAP HD BLANKING PLUG</p>	<p><b>FIT028A</b> <i>TDS</i></p>
	<p><b>FIT030B</b> 3/8" BSP MALE TO 1/4" BSP FEMALE REDUCER</p>	<p><b>FIT030B</b> <i>TDS</i></p>

	<p align="center"><b>FIT035A</b> STEM CONNECTOR 8mm x 1/8" BSP MALE</p>	<p align="center"><b>FIT035A</b> TDS</p>
	<p align="center"><b>FIT036B</b> TEE EQUAL 8mm</p> <p align="center"><b>FIT037B</b> TEE EQUAL 10mm</p>	<p align="center"><b>FIT036B</b> TDS</p> <p align="center"><b>FIT037B</b> TDS</p>
	<p align="center"><b>FIT038B</b> REDUCER 10mm – 8mm</p> <p align="center"><b>FIT039B</b> REDUCER 12mm – 10mm</p>	<p align="center"><b>FIT038B</b> TDS</p> <p align="center"><b>FIT039B</b> TDS</p>
	<p align="center"><b>FIT040B</b> CONNECTOR STRAIGHT 8mm EQUAL</p> <p align="center"><b>FIT041B</b> CONNECTOR STRAIGHT 10mm EQUAL</p> <p align="center"><b>FIT042B</b> CONNECTOR STRAIGHT 12mm EQUAL</p>	<p align="center"><b>FIT040B</b> TDS</p> <p align="center"><b>FIT041B</b> TDS</p> <p align="center"><b>FIT042B</b> TDS</p>
	<p align="center"><b>FIT043B</b></p> <p align="center">1/8" BSP (PARALLEL THREAD) SOC TOP HAT BLANKING PLUG</p>	<p align="center"><b>FIT043B</b> TDS</p>
	<p align="center"><b>FIT044B</b> BRANCH 1/8" BSP TO 6mm</p>	<p align="center"><b>FIT044B</b> TDS</p>

	<p><b>FIT046B</b> SEALING RING O-1-4</p>	<p><b>FIT046B</b> TDS</p>
	<p><b>FIT047B</b> 4mm ELBOW</p> <p><b>FIT048B</b> 6mm ELBOW</p>	<p><b>FIT047B</b> TDS</p> <p><b>FIT048B</b> TDS</p>
	<p><b>FIT049</b> INCREASER 6-8</p>	<p><b>FIT049</b> TDS</p>
	<p><b>FIT050B</b> 1/4" BSP (PARALLEL THREAD) SOC TOP HAT BLANKING PLUG</p>	<p><b>FIT050B</b> TDS</p>
 <p><b>FIT052B</b></p>	<p><b>FIT052B</b> ELBOW 6mm PUSHFIT x M5</p>	<p><b>FIT052B</b> TDS</p> <p><b>B158</b> Ventura</p>
 <p><b>FIT054C</b></p>	<p><b>FIT054C</b> 3.2 BARBED ELBOW FITTING</p>	<p><b>215890</b> Peters</p>
 <p><b>FIT056B</b></p>	<p><b>FIT056B</b> UNEQUAL STRAIGHT TUBE CONNECTOR 6-8</p>	<p><b>027345</b> Deans</p>

 <p><b>FIT058C</b></p>	<p><b>FIT058C</b> ELBOW COMPACT 6mm PUSH x 6mm MALE STEM</p>	<p><b>027176</b> <i>Deans</i></p>
	<p><b>FIT063B</b> REDUCER 8MM MALE TO 4MM PUSHIN</p>	<p><b>203753</b> <i>Peters</i></p>
 <p><b>FIT065B</b></p>	<p><b>FIT065B</b> CONNECTOR 6MM + 3x4MM</p>	<p><b>FIT065B</b> <i>TDS</i></p>
	<p><b>FIT067B</b> Y CONNECTOR 4mm - 1/8BSP MALE</p> <p><b>FIT068B</b> Y CONNECTOR 6mm - 1/8BSP MALE</p>	<p><b>170143</b> <i>Overton</i></p> <p><b>170140</b> <i>Overton</i></p>
	<p><b>FIT070C</b> EQUAL 6MM X 1/4 BSP MALE</p>	<p><b>FIT070C</b> <i>TDS</i></p>
	<p><b>FIT077</b> IN LINE FLOW CONTROL 8MM</p>	<p><b>FIT077</b> <i>TDS</i></p>

	<p><b>FIT079B</b> STUD M5 x 4MM PUSHIN</p>	<p><b>FIT079B</b> TDS</p>
	<p><b>FIT092</b> 1/8BSP SEALIN O-RING</p>	<p><b>FIT092</b> TDS</p>
	<p><b>FIT093B</b> 1/8" BSP (TAPPED THREAD) SOC BLANKING PLUG</p>	<p><b>FIT093B</b> TDS</p>
 <p>CAP001A</p>	<p><b>CAP001A</b> 35mm RD END CAP BLACK (FITTED TO TDS L500-05 BRG ASSY)</p>	<p><b>CAP001A</b> TDS</p>
	<p><b>CAP009</b> M16x40 BLACK NUT CAP</p>	<p><b>CAP009</b> TDS (ISAF DOOR GUIDE SPINDLE OPTARE VEHICLES)</p>
	<p><b>CAP016</b> NEOPRENE CAP – 1/2"</p> <p><b>CAP017</b> NEOPRENE CAP – 5/16" WILL FIT OVER M8 HEX HD SCREW</p>	<p><b>046458</b> Deans</p> <p><b>CAP017</b> TDS</p>
	<p><b>PLG001A</b> SABOT DOME PLUG</p>	<p><b>PLG001A</b> TDS</p>

	<p><b>PP004-NY</b> CLUTCH PIN NYLON</p>	<p><b>PP004-NY</b> TDS</p>
	<p><b>SCR009</b> WOODRUFF KEY - 0102432</p>	<p><b>0102432</b> PETERS</p>
	<p><b>SAB040-45</b> UNIVERSAL PLUG DOOR 28 BRACKET COVER</p>	<p><b>SAB040-45</b> TDS More information similar product See <b>SABOT COVER</b> file in SPARE PART IMAGES</p>
	<p><b>SPG002A</b> ATF TORSION SPRING</p>	<p><b>SPG002A</b> TDS</p>
	<p><b>STP010</b> ATF STRIKER STOP</p>	<p><b>STP010</b> TDS</p>
	<p><b>ROD001-C-50</b> LOCK ROD CRANKED 50RAD R1</p>	<p><b>ROD001-C-50</b> TDS</p>
	<p><b>A741</b> CABLE FIXER 4mm</p>	<p><b>A741</b> Ventura <b>WRIGHTBUS IG4</b></p>



	<p><b>A757</b> RETAINING RING DIN 471 A15 x 1 ST</p>	<p><b>A757</b> <i>Ventura</i></p>
	<p><b>A889</b> DDOR STOP</p>	<p><b>A889</b> <i>Ventura</i></p>
	<p><b>B325</b> CIRCLIP DIN 471 10x1 A2</p>	<p><b>B325</b> <i>Ventura</i> <b>WRIGHTBUS PS2</b></p>
	<p><b>B362</b> SEAL ¼</p>	<p><b>B362</b> <i>Ventura</i></p>
	<p><b>C199</b> PLASTIC HANDLE</p>	<p><b>C199</b> <i>Ventura</i></p>
	<p><b>C251</b> PLUG M12x1.5</p>	<p><b>C251</b> <i>Ventura</i></p>

	<p><b>C272</b> HANDRAIL NYLON CAP</p>	<p><b>C272</b> <i>Ventura</i></p>
	<p><b>C395</b> RUBBER BRUSH 50mm NBR 65 (IG CYLINDERS)</p>	<p><b>C395</b> <i>Ventura</i></p>
	<p><b>C492</b> VIBRATION DAMPER 20x15</p>	<p><b>C492</b> <i>Ventura</i></p>
	<p><b>C731</b> KEY DIN 6885 A 3x3x16</p>	<p><b>C731</b> <i>Ventura</i></p>
	<p><b>D538</b> THREAD BLOCK 2xM12</p>	<p><b>D538</b> <i>Ventura</i></p>
 <p><b>D551</b></p>	<p><b>D551</b> DOOR SHAFT</p>	<p><b>D551</b> <i>Ventura</i></p>

	<p><b>E234</b> LUBRICATOR NIPPLE M6-180</p>	<p><b>E234</b> <i>Ventura</i> <b>WRIGHTBUS PS2</b></p>
	<p><b>E974</b> Flow Regulator Ø6 Male to Ø6 female</p>	<p><b>E974</b> <i>Ventura</i> <b>SCANIA OMNICITY DD IG3</b></p>
	<p><b>G202</b> RUBBER ENDSTOP</p>	<p><b>G202</b> <i>Ventura</i></p>
	<p><b>G714</b> Y CONNECTOR 6MM PUSHIN</p>	<p><b>FIT074B</b> TDS <b>G714</b> <i>Ventura</i> <b>WRIGHTBUS PS2</b></p>
	<p><b>G677</b> TUBE ENLARGER 6MM STEM &gt; 8MM PUSHIN</p>	<p><b>G677</b> <i>Ventura</i> <b>FIT082B</b> TDS</p>
	<p><b>G756</b> RETAINING CLIP</p>	<p><b>G756</b> <i>Ventura</i></p>

	<p><b>G915</b> ELBOW CONNECTOR 6-1/4 (EARLIER RODLESS CYLINDERS) <b>RUNOUT 2014</b></p> <p><b>*SEE UPGRADE PART M691</b></p>	<p><b>G915</b> <i>Ventura</i></p>
	<p><b>M691</b> ELBOW CONNECTOR 6-1/4 (LATER RODLESS CYLINDERS)</p> <p><b>* UPGRADE TO PART G915</b></p>	<p><b>M691</b> <i>Ventura</i></p>
	<p><b>VA7269</b> ELBOW CONNECTOR 6-1/4 (LATEST RODLESS CYLINDERS)</p> <p><b>* SEP16 &gt;REPLACEMENT FOR M691/G915</b></p>	<p><b>VA7269</b> <i>Ventura</i></p>
	<p><b>H110</b> PIN</p>	<p><b>H110</b> <i>Ventura</i></p>
	<p><b>H685</b> HANDRAIL END PIECE</p>	<p><b>H685</b> <i>Ventura</i></p>
	<p><b>H706</b> BUSH 10-6,5 L=12</p>	<p><b>H706</b> <i>Ventura</i></p>

	<p><b>H889</b> None return valve 1/4BSP MALE to 8mm con</p>	<p><b>H889</b> <i>Ventura</i> ADL</p>
 <p>H908</p>	<p><b>H908</b> T-CONNECTOR STEM 4mm</p>	<p><b>H908</b> <i>Ventura</i></p>
	<p><b>I030</b> REDUCER FITTING M16x1.8 ASS</p>	<p><b>I030</b> <i>Ventura</i></p>
	<p><b>I197</b> NIPPLE M12x1,5 / M16x1,5 WABCO</p>	<p><b>I197</b> <i>Ventura</i></p>
	<p><b>I462</b> PU Cord (for Potentiometer Bush)</p>	<p><b>I462</b> <i>Ventura</i></p>
	<p><b>I571</b> PLUG</p>	<p><b>I571</b> <i>Ventura</i></p>

	<p><b>I572</b> GROMMET 6x9x1.5</p>	<p><b>I572</b> <i>Ventura</i> <b>WRIGHTBUS IG4</b></p>
	<p><b>J199</b> COVERING CAP</p>	<p><b>J199</b> <i>Ventura</i></p>
	<p><b>J242</b> LEVER STRIP</p>	<p><b>J242</b> <i>Ventura</i> <b>WRIGHTBUS PS2</b></p>
	<p><b>J353</b> TORSION SPRING</p>	<p><b>J353</b> <i>Ventura</i></p>
	<p><b>J357</b> HINGE ROD</p>	<p><b>J357</b> <i>Ventura</i></p>
	<p><b>J405</b> CATCH BLOCK BOTTOM SUPPORT PS</p>	<p><b>J405</b> <i>Ventura</i></p>

	<p><b>J593</b> LEVER BLOCK</p>	<p><b>J593</b> <i>Ventura</i></p>
	<p><b>K745</b> TORSION SPRING IG3 FLAP</p>	<p><b>K745</b> <i>Ventura</i></p>
	<p><b>M236</b> SPACER POM L=20</p>	<p><b>M236</b> <i>Ventura</i></p>
	<p><b>M414</b> DOOR PROFILE L463 - PLUG FOR SENS EDGE WIRE ENTRY</p>	<p><b>M414</b> <i>Ventura</i> <b>WRIGHTBUS IG4</b></p>
	<p><b>N181</b> T-CONNECTOR 2 x 6mm. 3 x 4mm</p>	<p><b>N181</b> <i>Ventura</i></p>

	<p><b>N860</b> TOGGLE NUT M8</p>	<p><b>N860</b> <i>Ventura</i> <b>WRIGHTBUS PS2</b></p>
	<p><b>N944</b> PLUG FOR HOLE DIA 13 (IG PROFILE)</p>	<p><b>N944</b> <i>Ventura</i> <b>WRIGHTBUS IG4</b></p>
	<p><b>O658</b> CATCH PIN BENDED DOOR</p>	<p><b>O658</b> <i>Ventura</i></p>
	<p><b>O689</b> M16x60 (1.5) SOC HD SCREW</p>	<p><b>O689</b> <i>Ventura</i></p>
	<p><b>O699</b> SOFT STOPPER ASSY</p>	<p><b>O699</b> <i>Ventura</i></p>
	<p><b>P532</b> ELBOW CONNECTOR DIA 6 G1-8</p>	<p><b>P532</b> <i>Ventura</i> <b>WRIGHTBUS PS2</b></p>



	<p><b>P533</b> SILENCER G1-8 (SPOOL VALVES)</p>	<p><b>P533</b> <i>Ventura</i> <b>PNE035C</b> <i>TDS</i></p>
	<p><b>P537</b> ELBOW CONNECTOR DIA6 G1-4 (IG4 FRONT DOOR CYLINDERS)</p>	<p><b>P537</b> <i>Ventura</i> <b>WRIGHTBUS IG4</b></p>
	<p><b>Q792</b> RUBBER LINED 18MM P CLIP</p>	<p><b>Q792</b> <i>Ventura</i></p>
	<p><b>Q916</b> CATCH BLOCK BENDED DOOR</p>	<p><b>Q916</b> <i>Ventura</i></p>
	<p><b>S685</b> END STOP ASSY M12x60</p>	<p><b>S685</b> <i>Ventura</i> <b>MELLOR ORION RS</b></p>

	<p><b>T778</b> GUIDE SHAFT STOP</p>	<p><b>T778</b> <i>Ventura</i></p>
	<p><b>VA0134</b> OVERCENTRE SOFT STOPPER</p>	<p><b>VA0134</b> <i>Ventura</i></p>
	<p><b>VA1109</b> MOUNTING PLATE SPINDLE NUT</p>	<p><b>VA1109</b> <i>Ventura</i></p>
	<p><b>VC0950</b> OBSTRUCT TEST TOOL</p>	<p><b>VC0950</b> <i>Ventura</i></p>