

TDS PRODUCT IMAGE SHEET – CATEGORY > FITTINGS & FIXTURES

Image	TDS Part Number & Description	OE & Alternative Part References
	<p>FIT001A 4mm BLANKING PLUG</p> <p>FIT002A 6mm BLANKING PLUG</p> <p>FIT057 8mm BLANKING PLUG</p>	<p>203197 <i>Peters</i></p> <p>060005 <i>Deans</i></p> <p>203198 <i>Peters</i></p> <p>060051 <i>Deans</i></p> <p>FIT057 <i>TDS</i></p>
	<p>FIT003A CONNECTOR Y 4mm SLIM</p>	<p>203258 <i>Peters</i></p> <p>0104644 <i>Deans</i></p>
	<p>FIT004B 4mm x 1/8" BSP ELBOW</p> <p>FIT005B 4mm x 1/4" BSP ELBOW</p> <p>FIT006B 6mm x 1/8" BSP ELBOW</p> <p>FIT007B 6mm x 1/4" BSP ELBOW</p> <p>FIT008B 8mm x 1/8" BSP ELBOW</p> <p>FIT009B 8mm x 1/4" BSP ELBOW</p>	<p>203403 <i>Peters</i></p> <p>203404 <i>Peters</i></p> <p>203405 <i>Peters</i></p> <p>060017 <i>Deans</i></p> <p>170081 <i>Deans</i></p> <p>203406 <i>Peters</i></p> <p>030534 <i>Deans</i></p> <p>060011 <i>Deans</i></p> <p>203407 <i>Peters</i></p> <p>203408 <i>Peters</i></p>

	<p>FIT010A 8mm x 1/4" BSP MALE STUD</p>	<p>203675 <i>Peters</i> 060034 <i>Deans</i></p>
	<p>FIT011B 6mm x 1/4" BSP MALE STUD</p>	<p>203677 <i>Peters</i> 060003 <i>Deans</i></p>
	<p>FIT012B 4mm x 1/8" BSP MALE STUD</p>	<p>203678 <i>Peters</i></p>
	<p>FIT013B 6mm x 1/8" BSP MALE STUD</p>	<p>203679 <i>Peters</i></p>
	<p>FIT032B 8mm x 1/8" BSP MALE STUD</p>	<p>FIT032B <i>TDS</i></p>
	<p>FIT079B 4mm x M5 MALE STUD</p>	<p>FIT079B <i>TDS</i></p>
 <p>FIT014A</p>	<p>FIT014A 4mm x 1/8" BSP FEMALE STUD</p>	<p>203681 <i>Peters</i></p>
	<p>FIT033A 8mm x 1/4" BSP FEMALE STUD</p>	<p>FIT033A <i>TDS</i></p>
	<p>FIT034A 6mm x 1/4" BSP FEMALE STUD</p>	<p>FIT034A <i>TDS</i></p>
	<p>FIT015B 6mm EQUAL TEE</p>	<p>203731 <i>Peters</i> 060010 <i>Deans</i> C363 <i>Ventura</i></p>
	<p>FIT016B 4mm EQUAL TEE</p>	<p>203732 <i>Peters</i> 060009 <i>Deans</i> A751 <i>Ventura</i></p>

 <p>FIT019B</p>	<p>FIT019B 6mm MALE 4mm FEMALE REDUCER</p>	<p>203754 <i>Peters</i> 060052 <i>Deans</i> H909 <i>Ventura</i></p>
	<p>FIT020A 8mm TO 6mm REDUCER</p>	<p>203755 <i>Peters</i></p>
	<p>FIT023T-01 ELBOW TAIL PIECE 4M-6F</p>	<p>215887 <i>Peters</i></p>
	<p>FIT025B CONNECTOR STRAIGHT 4mm EQUAL FIT031B CONNECTOR STRAIGHT 6mm EQUAL</p>	<p>215891 <i>Peters</i> FIT031B <i>TDS</i></p>
 <p>FIT026B</p>	<p>FIT026B M5 x 4MM PUSH IN ELBOW</p>	<p>216993-28 <i>Peters</i></p>
	<p>FIT028C 1/8" BSP (PARALLEL THREAD) SOC CAP HD BLANKING PLUG</p>	<p>FIT028A <i>TDS</i></p>
	<p>FIT030B 3/8" BSP MALE TO 1/4" BSP FEMALE REDUCER</p>	<p>FIT030B <i>TDS</i></p>

	<p>FIT035A STEM CONNECTOR 8mm x 1/8" BSP MALE</p>	<p>FIT035A TDS</p>
	<p>FIT036B TEE EQUAL 8mm</p> <p>FIT037B TEE EQUAL 10mm</p>	<p>FIT036B TDS</p> <p>FIT037B TDS</p>
	<p>FIT038B REDUCER 10mm – 8mm</p> <p>FIT039B REDUCER 12mm – 10mm</p>	<p>FIT038B TDS</p> <p>FIT039B TDS</p>
	<p>FIT040B CONNECTOR STRAIGHT 8mm EQUAL</p> <p>FIT041B CONNECTOR STRAIGHT 10mm EQUAL</p> <p>FIT042B CONNECTOR STRAIGHT 12mm EQUAL</p>	<p>FIT040B TDS</p> <p>FIT041B TDS</p> <p>FIT042B TDS</p>
	<p>FIT043B 1/8" BSP (PARALLEL THREAD) SOC TOP HAT BLANKING PLUG</p>	<p>FIT043B TDS</p>
	<p>FIT044B BRANCH 1/8" BSP TO 6mm</p>	<p>FIT044B TDS</p>

	<p>FIT046B SEALING RING O-1-4</p>	<p>FIT046B TDS</p>
	<p>FIT047B 4mm ELBOW</p> <p>FIT048B 6mm ELBOW</p>	<p>FIT047B TDS</p> <p>FIT048B TDS</p>
	<p>FIT049 INCREASER 6-8</p>	<p>FIT049 TDS</p>
	<p>FIT050B 1/4" BSP (PARALLEL THREAD) SOC TOP HAT BLANKING PLUG</p>	<p>FIT050B TDS</p>
 <p>FIT052B</p>	<p>FIT052B ELBOW 6mm PUSHFIT x M5</p>	<p>FIT052B TDS</p> <p>B158 Ventura</p>
 <p>FIT054C</p>	<p>FIT054C 3.2 BARBED ELBOW FITTING</p>	<p>215890 Peters</p>
 <p>FIT056B</p>	<p>FIT056B UNEQUAL STRAIGHT TUBE CONNECTOR 6-8</p>	<p>027345 Deans</p>

 <p>FIT058C</p>	<p>FIT058C ELBOW COMPACT 6mm PUSH x 6mm MALE STEM</p>	<p>027176 <i>Deans</i></p>
	<p>FIT063B REDUCER 8MM MALE TO 4MM PUSHIN</p>	<p>203753 <i>Peters</i></p>
 <p>FIT065B</p>	<p>FIT065B CONNECTOR 6MM + 3x4MM</p>	<p>FIT065B <i>TDS</i></p>
	<p>FIT067B Y CONNECTOR 4mm - 1/8BSP MALE</p> <p>FIT068B Y CONNECTOR 6mm - 1/8BSP MALE</p>	<p>170143 <i>Overton</i></p> <p>170140 <i>Overton</i></p>
	<p>FIT070C EQUAL 6MM X 1/4 BSP MALE</p>	<p>FIT070C <i>TDS</i></p>
	<p>FIT077 IN LINE FLOW CONTROL 8MM</p>	<p>FIT077 <i>TDS</i></p>

	<p>FIT079B STUD M5 x 4MM PUSHIN</p>	<p>FIT079B TDS</p>
	<p>FIT092 1/8BSP SEALIN O-RING</p>	<p>FIT092 TDS</p>
	<p>FIT093B 1/8" BSP (TAPPED THREAD) SOC BLANKING PLUG</p>	<p>FIT093B TDS</p>
	<p>GDE001A GUIDE SHOE</p>	<p>GDE001A TDS (ALL TREKA BUS VEHICLES)</p>
 <p>CAP001A</p>	<p>CAP001A 35mm RD END CAP BLACK (FITTED TO TDS L500-05 BRG ASSY)</p>	<p>CAP001A TDS</p>
	<p>CAP009 M16x40 BLACK NUT CAP</p>	<p>CAP009 TDS (ISAF DOOR GUIDE SPINDLE OPTARE VEHICLES)</p>
	<p>CAP016 NEOPRENE CAP – 1/2"</p> <p>CAP017 NEOPRENE CAP – 5/16" WILL FIT OVER M8 HEX HD SCREW</p>	<p>046458 Deans</p> <p>CAP017 TDS</p>

	<p>PLG001A SABOT DOME PLUG</p>	<p>PLG001A TDS</p>
	<p>PLG005 SDIA NYLON PLUG - DEANS KKT</p>	<p>100603 Deans</p>
	<p>PP004-NY CLUTCH PIN NYLON</p>	<p>PP004-NY TDS</p>
	<p>SCR009 WOODRUFF KEY - 0102432</p>	<p>0102432 PETERS</p>
	<p>SAB040-45 UNIVERSAL PLUG DOOR 28 BRACKET COVER</p>	<p>SAB040-45 TDS More information similar product See SABOT COVER file in SPARE PART IMAGES</p>
	<p>SPG002A ATF TORSION SPRING</p>	<p>SPG002A TDS</p>
	<p>STP010 ATF STRIKER STOP</p>	<p>STP010 TDS</p>

	<p>ROD001-C-50 LOCK ROD CRANKED 50RAD R1</p>	<p>ROD001-C-50 TDS</p>
	<p>A741 CABLE FIXER 4mm</p>	<p>A741 Ventura WRIGHTBUS IG4</p>
	<p>A757 RETAINING RING DIN 471 A15 x 1 ST</p>	<p>A757 Ventura</p>
	<p>A889 DDOR STOP</p>	<p>A889 Ventura</p>
	<p>B325 CIRCLIP DIN 471 10x1 A2</p>	<p>B325 Ventura WRIGHTBUS PS2</p>
	<p>B362 SEAL ¼</p>	<p>B362 Ventura</p>
	<p>C199 PLASTIC HANDLE</p>	<p>C199 Ventura</p>

	<p>C251 PLUG M12x1.5</p>	<p>C251 <i>Ventura</i></p>
	<p>C272 HANDRAIL NYLON CAP</p>	<p>C272 <i>Ventura</i></p>
	<p>C395 RUBBER BRUSH 50mm NBR 65 (IG CYLINDERS)</p>	<p>C395 <i>Ventura</i></p>
	<p>C492 VIBRATION DAMPER 20x15</p>	<p>C492 <i>Ventura</i></p>
	<p>C731 KEY DIN 6885 A 3x3x16</p>	<p>C731 <i>Ventura</i></p>
	<p>D538 THREAD BLOCK 2xM12</p>	<p>D538 <i>Ventura</i></p>

 <p>D551</p>	<p>D551 DOOR SHAFT</p>	<p>D551 <i>Ventura</i></p>
	<p>E234 LUBRICATOR NIPPLE M6-180</p>	<p>E234 <i>Ventura</i> WRIGHTBUS PS2</p>
	<p>E974 Flow Regulator Ø6 Male to Ø6 female</p>	<p>E974 <i>Ventura</i> SCANIA OMNICITY DD IG3</p>
	<p>G202 RUBBER ENDSTOP</p>	<p>G202 <i>Ventura</i></p>
	<p>G714 Y CONNECTOR 6MM PUSHIN</p>	<p>FIT074B TDS G714 <i>Ventura</i> WRIGHTBUS PS2</p>
	<p>G677 TUBE ENLARGER 6MM STEM > 8MM PUSHIN</p>	<p>G677 <i>Ventura</i> FIT082B TDS</p>

	<p>G756 RETAINING CLIP</p>	<p>G756 <i>Ventura</i></p>
	<p>G915 ELBOW CONNECTOR 6-1/4 (EARLIER RODLESS CYLINDERS) RUNOUT 2014 *SEE UPGRADE PART M691</p>	<p>G915 <i>Ventura</i></p>
	<p>H916 SCREW DIN 7981 ST4.2x13 C-H DP</p>	<p>H916 <i>Ventura</i></p>
	<p>M691 ELBOW CONNECTOR 6-1/4 (LATER RODLESS CYLINDERS) * UPGRADE TO PART G915</p>	<p>M691 <i>Ventura</i></p>
	<p>VA7269 ELBOW CONNECTOR 6-1/4 (LATEST RODLESS CYLINDERS) * SEP16 >REPLACEMENT FOR M691/G915</p>	<p>VA7269 <i>Ventura</i></p>
	<p>H110 PIN</p>	<p>H110 <i>Ventura</i></p>

	<p>H685 HANDRAIL END PIECE</p>	<p>H685 <i>Ventura</i></p>
	<p>H706 BUSH 10-6,5 L=12</p>	<p>H706 <i>Ventura</i></p>
	<p>H889 None return valve 1/4BSP MALE to 8mm con</p>	<p>H889 <i>Ventura</i> ADL</p>
 <p>H908</p>	<p>H908 T-CONNECTOR STEM 4mm</p>	<p>H908 <i>Ventura</i></p>
	<p>I030 REDUCER FITTING M16x1.8 ASS</p>	<p>I030 <i>Ventura</i></p>
	<p>I197 NIPPLE M12x1,5 / M16x1,5 WABCO</p>	<p>I197 <i>Ventura</i></p>

	<p>I462 PU Cord (for Potentiometer Bush)</p>	<p>I462 <i>Ventura</i></p>
	<p>I571 PLUG</p>	<p>I571 <i>Ventura</i></p>
	<p>I572 GROMMET 6x9x1.5</p>	<p>I572 <i>Ventura</i> WRIGHTBUS IG4</p>
	<p>J199 COVERING CAP</p>	<p>J199 <i>Ventura</i></p>
	<p>J242 LEVER STRIP</p>	<p>J242 <i>Ventura</i> WRIGHTBUS PS2</p>
	<p>J353 TORSION SPRING</p>	<p>J353 <i>Ventura</i></p>

	<p>J357 HINGE ROD</p>	<p>J357 <i>Ventura</i></p>
	<p>J405 CATCH BLOCK BOTTOM SUPPORT PS</p>	<p>J405 <i>Ventura</i></p>
	<p>J593 LEVER BLOCK</p>	<p>J593 <i>Ventura</i></p>
	<p>K745 TORSION SPRING IG3 FLAP</p>	<p>K745 <i>Ventura</i></p>
	<p>M236 SPACER POM L=20</p>	<p>M236 <i>Ventura</i></p>

	<p>M414 DOOR PROFILE L463 - PLUG FOR SENS EDGE WIRE ENTRY</p>	<p>M414 <i>Ventura</i> WRIGHTBUS IG4</p>
	<p>N181 T-CONNECTOR 2 x 6mm. 3 x 4mm</p>	<p>N181 <i>Ventura</i></p>
	<p>N860 TOGGLE NUT M8</p>	<p>N860 <i>Ventura</i> WRIGHTBUS PS2</p>
	<p>N944 PLUG FOR HOLE DIA 13 (IG PROFILE)</p>	<p>N944 <i>Ventura</i> WRIGHTBUS IG4</p>
	<p>O658 CATCH PIN BENDED DOOR</p>	<p>O658 <i>Ventura</i></p>
	<p>O689 M16x60 (1.5) SOC HD SCREW</p>	<p>O689 <i>Ventura</i></p>

	<p>O699 SOFT STOPPER ASSY</p>	<p>O699 <i>Ventura</i></p>
	<p>P532 ELBOW CONNECTOR DIA 6 G1-8</p>	<p>P532 <i>Ventura</i> WRIGHTBUS PS2</p>
	<p>P533 SILENCER G1-8 (SPOOL VALVES)</p>	<p>P533 <i>Ventura</i> PNE035C TDS</p>
	<p>P537 ELBOW CONNECTOR DIA6 G1-4 (IG4 FRONT DOOR CYLINDERS)</p>	<p>P537 <i>Ventura</i> WRIGHTBUS IG4</p>
	<p>Q792 RUBBER LINED 18MM P CLIP</p>	<p>Q792 <i>Ventura</i></p>
	<p>Q916 CATCH BLOCK BENDED DOOR</p>	<p>Q916 <i>Ventura</i></p>

	<p>S685 END STOP ASSY M12x60</p>	<p>S685 <i>Ventura</i> MELLOR ORION RS</p>
	<p>T778 GUIDE SHAFT STOP</p>	<p>T778 <i>Ventura</i></p>
	<p>VA0134 OVERCENTRE SOFT STOPPER</p>	<p>VA0134 <i>Ventura</i></p>
	<p>VA0772 Guide Ring Spiral Cable</p>	<p>VA0772 <i>Ventura</i></p>
	<p>VA1109 MOUNTING PLATE SPINDLE NUT</p>	<p>VA1109 <i>Ventura</i></p>
	<p>VC0950 OBSTRUCT TEST TOOL</p>	<p>VC0950 <i>Ventura</i></p>