

TDS PRODUCT IMAGE SHEET – CATEGORY > **BUTTONS**


Image	TDS Part Number & Description	OE & Alternative Part References (WHERE FITTED)
	BUT001-ASY-P DRIVERS DOUBLE FLUSH BUTTON PNEUMATIC	216370 <i>Peters</i> 214185 <i>Peters</i> 032289 <i>Deans</i> D23582 <i>Deans</i>
	BUT002-ASY-P INTERNAL DOUBLE BUTTON PNEUMATIC	216371 <i>Peters</i> 214186 <i>Peters</i> D23581 <i>Deans</i>
	BUT003-ASY-P EXTERNAL EMERGENCY FLUSH BUTTON PNEUMATIC	216372 <i>Peters</i> 214187 <i>Peters</i> 031145 <i>Deans</i>
	BUT003-ASY-PC EXTERNAL EMERGENCY FLUSH BUTTON PNEUMATIC BOOTED	BUT003-ASY-PC <i>TDS</i>
	BUT003-ASY-PEC EXTERNAL EMERGENCY FLUSH BUTTON PNEUMATIC & ELECTRIC BOOTED	BUT003-ASY-PEC <i>TDS</i>
	BUT004-ASY-P INTERNAL SINGLE CLOSE FLUSH BUTTON PNEUMATIC	216373 <i>Peters</i> 215168 <i>Peters</i> 031176 <i>Deans</i>

	BUT005-ASY-P INTERNAL SINGLE OPEN FLUSH BUTTON PNEUMATIC	216374 <i>Peters</i> 215167 <i>Peters</i>
	BUT006-ASY-P INTERNAL EMERGENCY RAISED BUTTON PNEUMATIC	216375 <i>Peters</i> 031175 <i>Deans</i>
	BUT007-ASY DRIVERS DOUBLE FLUSH BUTTON ELECTRIC	216380 <i>Peters</i>
	BUT008-ASY INTERNAL DOUBLE BUTTON ELECTRIC	216381 <i>Peters</i>
	BUT009-ASY EXTERNAL EMERGENCY FLUSH BUTTON ELECTRIC	216382 <i>Peters</i> 031916 <i>Deans</i>
	BUT009-ASY-EC EXTERNAL EMERGENCY FLUSH BUTTON ELECTRIC BOOTED	BUT009-ASY-EC <i>TDS</i>
	BUT010-ASY INTERNAL SINGLE CLOSE FLUSH BUTTON ELECTRIC	216383 <i>Peters</i>


	BUT011-ASY INTERNAL SINGLE OPEN FLUSH BUTTON ELECTRIC	216384 <i>Peters</i>
	BUT012-ASY INTERNAL EMERGENCY RAISED BUTTON ELECTRIC	216385 <i>Peters</i>
	BUT013A BUTTON MICROSWITCH ELECTRIC	216388 <i>Peters</i> 026752 <i>Deans</i>
	BUT014-ASY-P SINGLE BLACK FLUSH BUTTON PNEUMATIC	216444 <i>Peters</i> 214931 <i>Peters</i> 0106342 <i>Deans</i>
	BUT015-ASY SINGLE BLACK FLUSH BUTTON ELECTRIC	216445 <i>Peters</i>
	BUT016-ASY-P DOUBLE FLUSH BUTTON ELECTRIC OPEN PNEUMATIC CLOSE	216518 <i>Peters</i>
	BUT017-ASY-P DOUBLE FLUSH BUTTON ELECTRIC & PNEUMATIC OPEN/CLOSE	217343 <i>Peters</i>





	BUT018 RED PUSH BUTTON S/P (NO) MOMENTARY. 12mm DIA 0.25 TAB CONNECTORS	BUT018 TDS
	BUT019 GREEN PUSH BUTTON S/P (NO) MOMENTARY. 12mm DIA 0.25 TAB CONNECTORS	BUT019 TDS
	BUT030B ILLUMINATED GREEN DRIVERS CLOSE BUTTON - HALOGEN (BULB = BUT032B)	216302 Peters
	BUT030B-LED ILLUMINATED GREEN DRIVERS CLOSE BUTTON - LED (BULB = BUT033B)	217756 Peters
	BUT031B ILLUMINATED RED DRIVERS OPEN BUTTON - HALOGEN (BULB = BUT032B)	216301 Peters
	BUT031B-LED ILLUMINATED RED DRIVERS OPEN BUTTON - LED (BULB = BUT033B)	217755 Peters
	BUT032B 24V HALO BULB FOR ILLUMINATED BUTTONS	216108 Peters


 LED BUT033B	BUT033B 24V LED BULB FOR ILLUMINATED BUTTONS	217754 <i>Peters</i>
	BUT036C RAMP REQUEST BUTTON	031595 <i>Deans</i>
	BUT037B ILLUMINATED EMERGENCY OPEN BUTTON	216414 <i>Peters</i>
	BUT039B-01 RED "DOOR OPEN" ILLUMINATED PUSH MOMENTARY BUTTON S/P (NO). 22mm DIA 2.8 TAB CONNECTORS	DEP-00348 <i>Wrights</i>
	BUT041B-01 GREEN "DOOR CLOSE" ILLUMINATED PUSH MOMENTARY BUTTON S/P (NO). 22mm DIA 2.8 TAB CONNECTORS	DEP-00347 <i>Wrights</i>
	BUT042T DOOR OPEN ILLUM ELEC BUTTON	BUT042T <i>TDS</i>
	BUT043T DOOR CLOSE ILLUM ELEC BUTTON	BUT043T <i>TDS</i>

	BUT046-ASY EXTERNAL EMERGENCY FLUSH BUTTON ELECTRIC (HOLD)	BUT046-ASY <i>TDS</i> (TREKA 16 from Jul14)
	BUT046-ASY-EC EXTERNAL EMERGENCY FLUSH BUTTON ELECTRIC (HOLD) BOOTED	BUT046-ASY-EC <i>TDS</i>
	UNIVERSAL RUB046-01 BUTTON BOOT CAN BE CUT TO SUIT ALL BUTTON VARIANTS	RUB046-01 <i>TDS</i> 
	BUT047 DRIVER OPEN-CLOSE ILLUMINATED RED BUTTON USED ON BCE DOORS WITH CONTROL BOX ELE904	11703062 <i>BCE</i>
	BUT048 ILLUM LED BLUE DISABLED ELEC BUTTON (4 PIN)  # 3MTR CABLE = ELE163	BUT048 <i>TDS</i>
	BUT049 ILLUM LED BLUE DISABLED/PRAM ELEC BUTTON (4PIN)  # 5MTR CABLE = ELE163	BUT049 <i>TDS</i>
	BUT050-01 ILLUM LED DOOR OPEN/CLOSE ELEC BUTTON (3PIN W/PROOF)	BUT050-01 <i>TDS</i>



 	BUT063 EXTERNAL PNE BUTTON MASATS	32310CEP <i>Masats</i>
 BUT202	BUT202C LARGE DOUBLE BUTTON PNEUMATIC	031143 <i>Deans</i>
 BUT204C	BUT204C LARGE DOUBLE BUTTON ELECTRIC	031142 <i>Deans</i>
 BUT300D	BUT300D RED PUSH BUTTON T3	021770 <i>Deans</i>
 BUT301D	BUT301D GREEN PUSH BUTTON T3	021771 <i>Deans</i>
 BUT302D	BUT302D CHROME BEZEL	021773 <i>Deans</i>
 BUT303D	BUT303D WHITE PUSH BUTTON T1	024880 <i>Deans</i>

	BUT304D WHITE PUSH BUTTON T3	026384 <i>Deans</i>
	BUT307 DOUBLE RAISED BUTTON PNEUMATIC (3 PORT)	025622 <i>Deans</i>
	BUT308 EMERGENCY OPEN SINGLE BUTTON	E28248 <i>Deans</i>
	BUT309 EXTERIOR EMERGENCY ASSY	D41327 <i>Deans</i>
	BUT311 DRIVERS EXIT DOOR CONTROL	D31315 <i>Deans</i>
	COV001 SINGLE BUTTON HINGED COVER	COV001 <i>TDS</i>
	COV005 SUNKEN DISH (EMERGENCY VALVE)	C08761 <i>Deans</i>


	COV008 RECESSED DOOR SWITCH COVER	COV008 <i>TDS</i>
	ELE098 MICROSWITCH N31075	065009 <i>Deans</i> 047739 <i>Deans</i>
	ELE158-01 3-WAY IP67 WATERPROOF MICROSWITCH (NO/NC) V3 ASSY	U181 <i>Ventura</i>
	ELE158-02 2-WAY IP67 WATERPROOF MICROSWITCH (NO/NC) V3 ASSY	ELE158-02 <i>TDS</i>
	FAS028 BUTTON FASCIA PLATE ROUND (EMERGENCY ONLY)	E20321 <i>Deans</i>
	VAL008P BUTTON MINIATURE PNEUMATIC VALVE (N/C)	216389 <i>Peters</i> 216993-87 <i>Peters</i> K922 <i>Ventura</i>

	L169 BUTTON MINIATURE PNEUMATIC VALVE (N/O)	L169 <i>Ventura</i>
	C250 ELECTRIC PUSH BUTTON N/O	C250 <i>Ventura</i> POLISH SCANIA OMNICITY DD IG3/PS
	D260 RED PUSH BUTTON	D260 <i>Ventura</i>
	D333 DISABLED BLUE ILLUMINATED BUTTON (SINGLE GLAZE)	D333 <i>Ventura</i> EAST LANCS SD PS + OLYMPUS DD PS
	F975 DISABLED BLUE ILLUMINATED BUTTON (DOUBLE GLAZE)	F975 <i>Ventura</i> WRIGHTBUS STREETCAR PS
	F995 OPEN GREEN ILLUMINATED BUTTON – 1 SIDE	F995 <i>Ventura</i> WRIGHTBUS STREETCAR PS




Copyright © 2018 Transport Door Solutions Ltd. All Rights Reserved.






	I003 RED ELEC PUSH BUTTON	I003 <i>Ventura</i>
	I226 ELECTRIC PUSHBUTTON NO	I226 <i>Ventura</i> WRIGHTBUS STREETLITE IGE ADLE200EV
	I470 EMERGENCY OPEN RAISED BUTTON PNEUMATIC (FESTO)	I470 <i>Ventura</i> POLISH SCANIA OMNICITY DD IG3/PS
	I823 EMERGENCY OPEN FLUSH BUTTON ELECTRIC & PNEUMATIC	I823 <i>Ventura</i> ADL E200 SD IG4 + E300 SD IG4 + E400 DD IG3/IG4/PS, TEMSA SD IG4
	I824 DOUBLE BUTTON – ELECTRIC & PNEUMATIC OPEN/CLOSE	I824 <i>Ventura</i> ADL E200 SD IG4 + E300 SD IG4 + E400 DD IG3/IG4/PS, OPTARE SD PS VERSA + TEMPO
	I835 BUTTON CAPTRON BLUE DISABLED (WALL MOUNT)	I835 <i>Ventura</i>
	I898 INTERNAL EMERGENCY BUTTON PNEUMATIC	I898 <i>Ventura</i>


A black rectangular button with a red circular center. The word "DOORS" is printed above the button and "OPEN" below it. A small yellow label with "I951" is at the bottom.	I951 SINGLE RAISED BUTTON NC ELECTRIC/PNEUMATIC (P33408PE)	I951 <i>Ventura</i> TEMA SD IG4
A circular silver-colored emergency device with two vertical slots at the top. The word "EMERGENCY" is printed above the slots and "LIFT" below them. A small yellow label with "I978" is at the bottom.	I978 EMERGENCY DEVICE EXTERIOR INCL I992	I978 <i>Ventura</i>
A black rectangular device with a green circular center. The word "CLOSE" is printed in green on the center. A small yellow label with "I979" is at the bottom.	I979 EXTERIOR CLOSE DEVICE	I979 <i>Ventura</i>
A black door button cover with a silver-colored rectangular protrusion on the left side and a circular hole in the center.	J018 DOOR BUTTON COVER BLACK	J018 <i>Ventura</i>
A green rectangular label with a white circular center. The word "CLOSE" is printed in black on the green background. Dimensions are shown: 60mm height, 48mm width, 20.5mm top section height, and a hole diameter of Ø22.	J020 CLOSE DEVICE LABEL # REPLACEMENT FOR USE IN I979	J020 <i>Ventura</i>
A black cylindrical push button with a red top cap and three silver-colored electrical terminals at the bottom.	I226 ELEC PUSH BUTTON, N/O	I226 <i>Ventura</i> ADL E200 EV
A black circular emergency open raised button with a red center. The words "EMERGENCY", "PRESS", and "DOOR" are visible around the button. A small yellow label with "I992" is at the bottom.	I992 EMERGENCY OPEN RAISED BUTTON ELECTRIC/PNEUMATIC	I992 <i>Ventura</i>

	I994 BUTTON EAO 1 SIDE GREY WC # OCT14 - REPLACED BY Q149-KIT	I994 <i>Ventura</i> MCV SD EVOLUTION PS
	Q149-KIT (P661) BUTTON CAPTRON 1 SIDE GREY WC # REPLACES I994	P661 <i>Ventura</i> MCV SD EVOLUTION PS
	J019 PUSH BUTTON COVER HELLA	J019 <i>Ventura</i>
	J348 EMERGENCY COVER FIXED PLATE	J348 <i>Ventura</i>
	J353 EMERGENCY COVER TORSION SPRING	J353 <i>Ventura</i>
	J357 EMERGENCY COVER ROD	J357 <i>Ventura</i>
	J618 DOUBLE FLUSH BUTTON PNEUMATIC	J618 <i>Ventura</i> WRIGHTBUS ECLIPSE SD IG4, WRIGHTBUS GEMINI DD IG4 + STREETLITE SD IG4 + NBFL DD IG4/IG4 PLAT/PS

	J693 DOOR SWITCH COVER	J693 <i>Ventura</i>
	L061 EMERGENCY OPEN BUTTON N/O PNEUMATIC	L061 <i>Ventura</i>
	L062 (M970) EMERGENCY BUTTON EXTERIOR COVER	L062 <i>Ventura</i> WRIGHTBUS ECLIPSE SD IG4, WRIGHTBUS GEMINI DD IG4 + STREETLITE SD IG4, BLUEBIRD SD RS
	L063 EMERGENCY BUTTON INTERIOR COVER	L063 <i>Ventura</i> MCV SD 112/124RLE IG4, BLUEBIRD SD RS
	L866 PUSHBUTTON DOUBLE ASSY PNEU.	L866 <i>Ventura</i> MCV SD 112/124RLE IG4
	L876 EMERGENCY BUTTON	L876 <i>Ventura</i> MCV SD 112/124RLE IG4, BLUEBIRD SD RS

	M491 PUSHBUTTON + RUBBER SEAL	M491 <i>Ventura</i> MCV SD 112/124RLE IG4, BLUEBIRD SD RS
	M492 COVER OUTSIDE BUTTON (GREEN)	M492 <i>Ventura</i> BLUEBIRD SD RS
	M494 PUSHBUTTON GREEN ELECTRIC	M494 <i>Ventura</i> BLUEBIRD SD RS
	M692 PUSHBUTTON RED PNEUMATIC NC	M692 <i>Ventura</i>
	M699 COVER EMERGENCY BUTTON INSIDE	M699 <i>Ventura</i>
	M971 (M979) EMERGENCY OPEN BUTTON N/C PNEUMATIC/ELECTRIC	M971 <i>Ventura</i> WRIGHTBUS ECLIPSE SD IG4, WRIGHTBUS GEMINI DD IG4 + STREELITE SD IG4 + NBFL DD IG4/IG4 PLAT/PS
	M979 BUTTON EMERGENCY YELLOW PNEU NC + ELEC	M979 <i>Ventura</i> WRIGHTBUS ECLIPSE SD IG4, WRIGHTBUS GEMINI DD IG4 + STREELITE SD IG4 + NBFL DD IG4/IG4 PLAT/PS

	0749 COVER – EMERGENCY BUTTON	0749 <i>Ventura</i>
	0752 DOUBLE BUTTON ELECTRIC	0752 <i>Ventura</i>
	P078 EMERGENCY PUSH BUTTON PNEU/ELEC RED	P078 <i>Ventura</i>
	P079 EMERGENCY PUSH BUTTON PNEU NC/ELEC GREY/GREEN	P079 <i>Ventura</i>
	U181 3-WAY IP67 WATERPROOF MICROSWITCH (NO/NC) V3 ASSY	U181 <i>Ventura</i> ELE158-01 <i>TDS</i>
	U890 EMERGENCY COVER GREY - OPEN	U890 <i>Ventura</i>
	VA0006 EMERGENCY COVER GREY - CLOSE	VA0006 <i>Ventura</i>

	VA0124 EMERGENCY BUTTON GREY/RED PNEU NC + ELECTRIC	VA0124 <i>Ventura</i>
---	---	-------------------------------------