




TDS PRODUCT IMAGE SHEET >

VENTURA – NBFL/NRM (ROUTEMASTER) SHELFPLATE / DOOR MECHANISMS









Leaves 1 & 2 = Front IG4 Inward Glider

Leaves 3 & 4 = Mid PS Plug Slider

Leaves 5 & 6 = Rear IG4 Platform Inward Glider

Leaf 7 = Rear RS Platform Rapid Slider (instead of 5 & 6)

Image	TDS Part Number & Description	OE Part Numbers (SUPPLIED FOR DOOR SYSTEM)
	<p>A160 OBSTRUCTION DETECTION UNIT ASSY</p>	<p>A160 <i>Ventura</i> MID PS / REAR IG4 PLAT / REAR RS</p>
	<p>A358 PRESSURE SWITCH NC 2 BAR M12x1.5</p>	<p>A358 <i>Ventura</i> FRONT IG4 / REAR IG4 PLAT</p>
	<p>A368 MICROSWITCH OPEN/CLOSE ROLLER NC/NO</p>	<p>A368 <i>Ventura</i> MID PS</p>
	<p>A925 GUIDE ROLLER ASSY</p>	<p>A925 <i>Ventura</i> REAR RS</p>
	<p>B708 BEARING BUSH MFM-1216-10</p>	<p>B708 <i>Ventura</i> REAR RS</p>

	<p>C247 PNEUMATIC BASE CONTROL UNIT WABCO MTS (# ASSY = 1883)</p>	<p>C247 <i>Ventura</i> MID PS / REAR RS</p>
 <p>C 2 4 9</p>	<p>C249 PRESSURE SWITCH NO-4BAR (M12x1.5)</p>	<p>C249 <i>Ventura</i> REAR IG4 PLAT</p>
	<p>E529 PS GUIDE ROLLER</p>	<p>E529 <i>Ventura</i> MID PS</p>
 <p>F 0 3 4</p>	<p>F034 TUBE RESTRICTOR 6/4 - 1.1MM</p>	<p>F034 <i>Ventura</i> FRONT IG4</p>
	<p>F424 CABLE LOOM PS</p>	<p>F424 <i>Ventura</i> MID PS</p>
 <p>F586</p>	<p>F586 TUBE RESTRICTOR 6/4 - 1.3MM</p>	<p>F586 <i>Ventura</i> MID PS / REAR IG4 PLAT</p>

	<p>H618 WIRING LOOM</p>	<p>H618 <i>Ventura</i> FRONT IG4</p>
	<p>H694 DOUBLE FLUSH PNEUMATIC BUTTON</p>	<p>H694 <i>Ventura</i> FRONT IG4 / MID PS REAR IG4 PLAT / REAR RS</p>
	<p>I026 TUBE RESTRICTOR 6/4 - 1.7MM</p>	<p>I026 <i>Ventura</i> REAR RS</p>
	<p>I261 BEARING BUSH GFM-1618-17</p>	<p>I261 <i>Ventura</i> REAR RS</p>
	<p>I822 PRESSURE SWITCH NO-2BAR</p>	<p>I822 <i>Ventura</i> REAR RS</p>
	<p>I883 WABCO PNEU CONTROL VALVE ASSY MTS</p>	<p>I883 <i>Ventura</i> MID PS / REAR RS</p>

	<p>J278 SPIRAL CABLE ASSY RS</p>	<p>J278 <i>Ventura</i> REAR RS</p>
	<p>J618 DOUBLE FLUSH PNE BUTTON</p>	<p>J618 <i>Ventura</i> FRONT IG4 / MID PS / REAR IG4 PLAT</p>
	<p>K651 LINEAR BEARING 30MM</p>	<p>K651 <i>Ventura</i> REAR RS</p>
	<p>L062 COVER EMERG BUTTON YELLOW EXTERIOR</p>	<p>L062 <i>Ventura</i> REAR RS</p>
	<p>L312 MICROSWITCH SCHALTBAU</p>	<p>L312 <i>Ventura</i> MID PS / REAR IG4 PLAT / REAR RS</p>
	<p>L463 END STOP ASSY M12x50</p>	<p>L463 <i>Ventura</i> REAR RS</p>
	<p>L559 CONNECTING ROD M8x700 RS ASSY</p>	<p>L559 <i>Ventura</i> REAR IG4 PLAT</p>

	<p>M979 (M971) BUTTON EMERGENCY YELLOW PNEU NC + ELEC</p>	<p>M979 (M971) Ventura FRONT IG4 / MID PS REAR IG4 PLAT / REAR RS</p>
	<p>N427 PIVOT POINT</p>	<p>N427 Ventura REAR RS</p>
	<p>N670 SPIRAL CABLE ASSY IG4 NBFL</p>	<p>N670 Ventura REAR IG4 PLAT</p>
	<p>O430 BRUSH IG4 WRIGHT NBFL BEND</p>	<p>O430 Ventura</p>
	<p>O500 SPIRAL CABLE ASSY IG4</p>	<p>O500 Ventura FRONT IG4</p>
	<p>O574 PS DRIVE CABLE ASSY</p>	<p>O574 Ventura MID PS</p>
	<p>O578 RODLESS CYLINDER 32x815 ASSY (# REFURB OPTION = 0578-RK)</p>	<p>O578 Ventura MID PS</p>

 <p style="text-align: center;">0699</p>	<p style="text-align: center;">0699 SOFT STOPPER ASSY</p>	<p style="text-align: center;">0699 <i>Ventura</i> MID PS</p>
 <p style="text-align: center;">P517</p>	<p style="text-align: center;">P517 FILTER REGULATOR ASSY</p>	<p style="text-align: center;">P517 <i>Ventura</i> REAR RS</p>
 <p style="text-align: center;">P539</p>	<p style="text-align: center;">P539 CYLINDER PROXIMITY REED SWITCH IG</p>	<p style="text-align: center;">P539 <i>Ventura</i> FRONT IG4 / REAR IG4 PLAT</p>
	<p style="text-align: center;">P540 DOOR CYLINDER (IGP) 50x125 – NO REED REPLACES H836+7 BASE CYLINDER SEAL REPAIR KIT = P540-RK (REPLACED BY VB2290)</p>	<p style="text-align: center;">P540 <i>Ventura</i> WRIGHTBUS ECLIPSE SD IG4 + GEMINI DD IG4 + NBFL DD IG4/IG4 PLAT, ADL E200 SD IG4 + E300 SD IG4 + E400 DD IG4</p>
	<p style="text-align: center;">P542 VALVE BI-STABLE 24VDC DOUBLE 6MM</p>	<p style="text-align: center;">P542 <i>Ventura</i> FRONT IG4 / REAR IG4 PLAT</p>
	<p style="text-align: center;">P563 (K005) FILTER REGULATOR ASSY 6mm</p>	<p style="text-align: center;">P563 <i>Ventura</i> FRONT IG4 / MID PS</p>

	<p>P807 VALVE BI-STABLE 24VDC (# BASE VALVE)</p> <p>(# ASSY = P542)</p>	<p>P807 <i>Ventura</i> FRONT IG4 / REAR IG4 PLAT</p>
	<p>P542 VALVE BI-STABLE 24VDC ASSY</p> <p>(# BASE ASSY = P807)</p>	<p>P542 <i>Ventura</i> FRONT IG4 / REAR IG4 PLAT</p>
	<p>P862 OR LOGIC VALVE 4MM</p>	<p>P862 <i>Ventura</i> REAR RS</p>
	<p>Q003 5/2 VALVE MONO-STABLE KM/H INTERLOCK</p>	<p>Q003 <i>Ventura</i> MID PS, REAR RS</p>
	<p>Q673 5/2 VALVE 24V DV ASSY</p>	<p>Q673 <i>Ventura</i> REAR IG4 PLAT</p>
	<p>Q916 CATCH BLOCK BENDED DOOR</p>	<p>Q916 <i>Ventura</i></p>

	<p>S234 CYLINDER 63 x 125 EXT PISTON</p> <p># SEAL REPAIR KIT = VA2982</p>	<p>S234 <i>Ventura</i> REAR IG4 PLAT</p>
	<p>S503 OVERCENTER SOFT STOPPER</p>	<p>S503 <i>Ventura</i> REAR RS</p>
	<p>T896 CONNECTING ROD M8 SUB</p>	<p>T896 <i>Ventura</i> MID PS</p>
	<p>VA1588 SWITCH CAM SHAFT</p>	<p>VA1588 <i>Ventura</i> REAR RS</p>
	<p>VA3340 CABLE LOOM RS NBFL</p>	<p>VA3340 <i>Ventura</i> REAR RS</p>
	<p>VA3604 RODLESS CYLINDER 32x950 ASSY</p>	<p>VA3604 <i>Ventura</i> REAR RS</p>
	<p>VA3704 CABLE LOOM DOORLEAF 2/2 POLE</p>	<p>VA3704 <i>Ventura</i></p>

	<p>VA9729 RS BEARING HOUSING ASSY</p>	<p>VA9729 <i>Ventura</i></p>
	<p>VB2290 DOOR CYLINDER (IGP) 50x125 – NO REED REPLACES P540, H836+7 BASE CYLINDER SEAL REPAIR KIT = P540-RK</p>	<p>VB2290 <i>Ventura</i> FRONT IG4 / REAR IG4 PLAT</p>