


or = Denotes. Viewing direction for door orientation from **INSIDE** looking **OUT**

Note for
RHD=Right Hand Vehicles
If drawing refer to RH & LH this usually means
Right Hand & Left Hand orientation viewed from
INSIDE vehicle looking **OUT**., ie doorleaf No.1
would also be RH typically



RUB060 =(TDS) ELECTRIC SEN-EDGE
LONG LIPPED NOSING RUBBER



RUB061 =(TDS) ELECTRIC SEN-EDGE
SHORT LIPPED NOSING RUBBER



RUB006 =(TDS) PRESSURE SEN-EDGE
LONG LIPPED NOSING RUBBER



RUB025 =(TDS) PRESSURE SEN-EDGE
SHORT LIPPED NOSING RUBBER

Note for

LHD=Left Hand Vehicles
If drawing refer to RH & LH this usually means
Right Hand & Left Hand orientation viewed from
INSIDE vehicle looking **OUT**., ie doorleaf No.1
would also be LH typically

TDS DOOR SYSTEM

Title		Dwg No.	
NOSING RUBBERS VEHICLE ORIENTATION		INST-100-20	
Scale 1:1		1-1	
Drawn A WILSON		Rev 1	
Checked			
Date 24-03-2021			
tel: 01787 473000 fax: 01787 477040 sales@transportdoorsolutions.co.uk www.transportdoorsolutions.co.uk			
THIRD ANGLE PROJECTIONS ALL DIMENSIONS IN MM/INCHES			